




Key No.	Parts No.	Parts Name
2-9	G10-7901	SPOOL
1	F32-9507	DRAG KNOB
2	171-7701	DRAG WASHER RET
3	F09-4901	KEY WASHER
4	E13-6003	DRAG WASHER
5	373-3603	EARED WASHER
7	B07-5304	CLICK PAWL
8	E40-3101	CLICK SPRING
9	320-5901	CLICK RET
10	F09-4800	SPOOL WASHER A
11	F09-4701	SPOOL WASHER B
12	E46-2701	CLICK GEAR
13	F99-2301	MAIN SHAFT
14	340-6602	ROTOR NUT
15	F62-0307	ROTOR
16	B67-9304	LINE ROLLER SCREW
17	F61-9303	BAIL ARM
18	E49-3501	BAIL ARM SCREW
19	320-5901	BAIL ARM SCREW RET
20	F44-6302	ROLLER COLLAR
21	F44-6202	LINE ROLLER WASHER
22	F45-4901	LINE ROLLER
23	F47-3401	LINE ROLLER BUSHING
24	G10-7602	BAIL
25	B84-2102	BAIL HOLDER SCREW
26	E46-2101	BAIL TRIP LEVER
27	F18-0012	TRIGGER LEVER
28	E36-9901	TRIGGER SPRING
29	E37-0003	TRIGGER SCREW

Key No.	Parts No.	Parts Name
30	F12-8901	BAIL SPRING
31	F31-4512	BAIL SPRING COVER
32	E36-4202	BAIL HOLDER COVER SCREW
33	F31-4612	BAIL HOLDER COVER
34	F24-8901	A/R RATCHET
35	F20-1101	A/R PAWL SPRING B
36	F20-1001	A/R COLLAR
37	L03-6502	BALL BEARING
38	E52-0101	PINION GEAR
39	G07-0903	BODY
40	E00-7101	A/R PAWL SCREW
41	F19-9901	A/R PAWL
42	F19-9801	A/R PAWL SPRING A
43	E03-7801	BEARING RET SCREW
44	F19-5201	A/R CAM SPRING
45	F98-9301	A/R CAM
46	F98-9202	A/R LEVER
47	F98-9401	A/R LEVER SCREW
48	F13-1601	OSC GEAR COLLAR
49	G18-9301	OSC GEAR
50	F99-2201	OSC SLIDER
51	352-1505	OSC SLIDER SCREW
52	E52-0201	DRIVE GEAR
53	373-7808	DRIVE GEAR WASHER
54	F99-3405	SIDE COVER
55	E15-8602	SIDE COVER SCREW
56	G07-1001	HANDLE
57	F02-0201	HANDLE WASHER
58	B92-5012	HANDLE SCREW