




PARTS LIST

NO.	DESCRIPTION	PART NO.	NO.	DESCRIPTION	PART NO.
1	DRAG KNOB	1080798	33	SILENT RING	1080771
2	RETAINER RING	1080744	34	WASHER	1080771
3	WASHER	1080745	35	BALL BEARING	1080771
4	EARED WASHER	1080746	36	PINION GEAR	1080771
5	DRAG WASHER RETAINER RING	1080747	37	SCREW	1080771
6	SPOOL COMPLETE (2-9)	1080799	38	ANTI-REVERSE PAWL	1080771
7	CLICK GEAR	1080749	39	BALL BEARING SC	1080771
8	CLICK SPRING	1080750	40	BODY	1080801
9	WASHER	1080751	41	HANDLE SCREW CAP	1080801
10	CLICK WASHER	1080752	42	HANDLE SCREW CAP WASHER	1080771
11	SPOOL CLICK GEAR	1080753	43	ANTI-REVERSE LEVER SPRING	1080771
12	MAIN SHAFT	1080754	44	ANTI-REVERSE LEVER	1080771
13	ROTOR NUT	1080755	45	ANTI-REVERSE LEVER BUSHING	1080771
14	ROTOR NUT SCREW	1080756	46	ANTI-REVERSE LEVER SCREW	1080771
15	ROTOR	1080800	47	BUSHING	1080801
16	BAIL LEVER	1080757	48	DRIVE GEAR	1080801
17	KICK LEVER COVER	1080801	49	WASHER	1080801
18	KICK LEVER COVER SC	1080760	50	BODY COVER BALL BEARING	1080801
19	BAIL SCREW	1080761	51	OSCILLATING GEAR	1080801
20	BAIL ARM	1080802	52	OSCILLATING GEAR BUSHING	1080801
21	SCREW	1080763	53	SCREW	1080801
22	LINE ROLLER WASHER	1080764	54	SLIDER	1080801
23	LINE ROLLER	1080765	55	SLIDER SC	1080801
24	BUSHING	1080766	56	BODY COVER	1080801
25	BAIL ASSY	1080767	57	BODY COVER SCREW	1080801
26	BAIL HOLDER	1080803	58	BODY COVER SCREW	1080801
27	KICK LEVER	1080769	59	HANDLE ASSY	1080801
28	SPRING	1080770	60	ANTI-REVERSE BUTTON	1080801
29	SLIDER	1080771	61	ANTI-REVERSE BUTTON RETAINER	1080801
30	BAIL ARM COVER	1080804	62	REAR COVER	1080801
31	SILENT BUSHING	1080773	63	REAR COVER SC	1080801
32	SILENT SPRING	1080774			

ABU GARCIA SURF COMBO REEL