


SPINCASTING REEL JUPITER-Z25LD/X25LD



Key NO.	Parts No.	Parts Name	Key NO.	Parts No.	Parts Name
1	F23-1401	Front cover	35	F22-5001	Main shaft
2	B55-4001	Rotor nut	36	F23-0001	Ball bearing
3	F22-8701	Rotor assembly	37	F22-9201	Anti-reverse pawl spring
6	320-0351	Spool retainer	38	F22-9101	Anti-reverse ratchet
7	F23-0601	Drag washer	39	402-6401	Pinion gear
8	F22-9501	Spool assembly	40	F22-9301	Main shaft spring
9	F22-5201	Eared washer	41	F23-7401	Rear cover
10	F22-5301	Drag plate	42	E36-4202	Push button screw
11	F22-6201	Body	43	F23-6901	Push button collar
12	030-6001	Spool click spring	44	F23-7901	Push button
13	B93-3001	Spool click spring screw	45	F23-6701	Push button spring
14	F23-0801	Drag cam click spring	49	F31-5101	Drag lever spring
15	B93-3001	Drag cam click spring screw			
16	F23-6801	Set plate screw			
17	F23-0501	Drag screw			
18	F22-8901	Drag dial			
19	F23-0301	Drag dial holder			
20	L01-1702	Drag dial holder screw			
21	F22-9001	Anti-reverse pawl			
22	F23-7001	Anti-reverse pawl washer			
23	B93-3001	Anti-reverse pawl screw			
24	F23-0401	Drive shaft retainer			
25	F24-6100	Drive gear washer A			
26	F24-6101	Drive gear washer B			
27	F23-0201	Drive gear			
28	F22-5101	Drag cam			
29	B89-0801	Drag lever retainer			
30	F23-6601	Drag lever			
31	F23-1002	Handle assembly			
32	B55-4001	Handle nut			
33	F23-0701	Handle nut plate			
34	351-1803	Handle nut plate screw			

JUPITER-X25LD Special Parts

1	F24-5601	Front cover
11	F22-6202	Body
18	F22-8902	Drag dial
30	F24-5701	Drag lever
41	F24-1801	Rear cover
44	F24-1901	Push button
46	F23-1601	Bushing
47	F23-1501	Main shaft
48	371-6903	Pinion gear washer