


SPINNING REEL REGAL-Z1505BL



Key NO.	Parts No.	Parts Name
2-9	F33-0603	Spool assembly
1	F32-8503	Drag knob
2	F37-3301	Drag washer retainer
3	E46-7201	Key washer
4	E13-6001	Drag washer
5	373-3603	Eared washer
6	F33-0703	Spool assembly
7	B07-5304	Click pawl
8	E40-3101	Click spring
9	320-5901	Click retainer
10	E46-7101	Spool washer
11	270-6501	Click gear
12	E49-8401	Main shaft
13	F12-2301	Oscillating slider
14	351-0311	Oscillating slider screw
15	341-9201	Rotor nut
16	F33-1403	Rotor
17	B67-9306	Line roller screw
18	F17-3103	Bail arm
19	E49-3501	Bail arm screw
20	320-5901	Bail arm screw retainer
21	F06-6301	Line roller collar
22	F05-5601	Ball bearing A
23	F05-8901	Line roller
24	F33-1701	Bail assembly
25	B84-2102	Bail trip cam screw
26	E49-6401	Bail trip lever
27	E49-3405	Trigger lever
28	E36-9901	Trigger spring
29	E37-0002	Trigger screw

Key NO.	Parts No.	Parts Name
30	E49-6801	Bail spring
31	F32-4103	Bail spring cover
32	E24-8101	Bail spring cover screw
33	F32-6503	Bail trip cover
34	F12-2101	Anti-reverse pawl spring A
35	E49-8501	Anti-reverse ratchet
36	634-1301	Ball bearing B
37	F12-1601	Pinion gear
38	F33-1302	Body assembly
39	F12-5701	Anti-reverse pawl screw
40	F12-1901	Anti-reverse pawl
41	F12-3501	Anti-reverse pawl collar
42	F12-3401	Anti-reverse pawl spring B
43	E03-7801	Bearing retainer screw
44	F12-2001	Anti-reverse cam spring
45	F08-5123	Anti-reverse lever
46	F12-2201	Oscillating gear
47	E50-5801	Bearing washer
48	E30-6801	Ball bearing C
49	F12-1501	Drive gear
50	375-8502	Drive gear washer
51	634-1301	Ball bearing B
52	F33-1002	Side cover
53	E15-8602	Side cover screw
54	F33-1201	Handle assembly
55	501-8501	Handle collar
56	B92-5006	Handle lock screw
57	375-8502	Pinion washer