


SPINNING REEL TOURNAMENT-Z2500iT



Key No.	Parts No.	Parts Name
2-8	F44-7101	Spool assembly
1	F44-7301	Drag knob
2	F06-2601	Drag washer retainer
3	F01-6001	Click plate washer
4	E12-2803	Drag knob click plate
5	B36-0204	Drag washer
6	E15-0101	Eared washer
7	B65-2302	Key washer
8	F44-7201	Spool assembly
9	F06-2701	Spool washer
10	F44-6501	Main shaft assembly
11	B74-7702	Spool click leaf spring
12	341-9204	Rotor nut
13	F22-7901	Rotor nut holding plate
14	350-8912	Rotor nut holding plate screw
15	F44-5601	Rotor
16	F14-2004	Line roller screw
17	F45-4301	Bail arm
18	F34-5901	Bail arm screw
19	320-5901	Bail arm screw retainer
20	F44-6303	Line roller collar
21	F44-6202	Line roller washer
22	F45-4902	Line roller
23	F05-5601	Ball bearing A
24	F44-5701	Bail assembly
25	F11-5801	Bail spring shaft
26	E31-3901	Bail spring washer
27	F30-1301	Bail spring
28	F34-6003	Bail spring cover
29	F01-3703	Bail spring cover screw
30	F01-4301	Bail trip plate
31	F49-9201	Bail trip lever
32	F34-6603	Bail trip cover
33	F19-7203	Oiled washer
34	F15-3301	Roller clutch
35	F21-2501	Roller clutch retainer
36	F26-8501	Rotor washer
37	F15-5101	Spacing sleeve A
38	F15-1201	Anti-reverse ratchet
39	375-8507	Spacing sleeve B
40	F22-7801	Bearing retainer
41	F22-6801	Anti-reverse pawl collar
42	F22-6901	Anti-reverse pawl plate

Key No.	Parts No.	Parts Name
43	E45-4001	Anti-reverse pawl screw
44	F22-7001	Anti-reverse pawl
45	B30-4001	Bearing retainer screw
46	F22-7101	Anti-reverse pawl spring
47	F22-6701	Ball bearing B
48	F01-6903	Spacer
49	F37-1801	Pinion gear
50	E24-3301	Pinion collar
51	F44-5401	Body assembly
52	E26-8701	Anti-reverse cam spring
53	F01-2711	Anti-reverse lever
54	B33-9801	Worm shaft gear retainer
55	F13-0501	Worm shaft gear
56	F28-2101	Worm shaft bush
57	E33-2501	Bail bearing C
58	F28-2001	Worm shaft
59	F28-1902	Worm shield cover
60	F21-6402	Oscillating slider
61	E19-1202	Oscillating pawl
62	E19-1301	Oscillating pawl bush
63	375-0801	Oscillating pawl washer
64	E24-4901	Oscillating slider cover
65	E15-0203	Oscillating slider cover screw
66	375-4101	Worm shaft washer
67	F28-2201	Ball bearing D
68	F28-2301	Worm shaft retainer
69	F28-2401	Worm shaft collar
70	F01-6102	Water shield
71	F01-6212	Rear cover
72	F01-6302	Rear cover screw A
73	F01-7202	Rear cover screw B
74	F01-6401	Ball bearing E
75	E24-7009	Drive gear
76	375-8501	Drive gear washer
77	636-6401	Ball bearing F
78	F01-3206	Side cover
79	351-1106	Side cover screw
80	F40-4801	Handle collar
81	F04-5002	Handle screw
82	F14-3602	Handle screw cap
83	F49-9302	Handle assembly