


SPINNING REEL

TEAM DAIWA-S2500iT



Key

No.	Parts No.	Parts Name
2-6	F50-6801	Spool assembly
1	F17-0910	Drag knob
2	171-7701	Drag washer retainer
3	E13-6101	Key washer
4	E13-6001	Drag washer
5	E13-6201	Eared washer
6	F50-6901	Spool assembly
7	E39-4001	Spool washer
8	E12-0303	Click leaf spring holder
9	B74-7702	Spool click leaf spring
10	375-4202	Main shaft washer
11	E36-5301	Click gear
12	E50-2102	Main shaft
13	B99-5101	Rotor nut holding plate
14	351-1804	Rotor nut holding plate screw
15	341-9204	Rotor nut
16	F48-3002	Rotor assembly
17	B67-9309	Line roller screw
18	F48-1902	Bail arm
19	F48-7501	Bail arm screw
20	320-5901	Bail arm screw retainer
21	F44-6303	Line roller collar
22	F44-6202	Line roller washer
23	F05-5601	Ball bearing A
24	F45-4902	Line roller
25	F50-6601	Bail assembly
26	F24-6801	Bail spring shaft
27	E39-0601	Bail spring
28	F48-2002	Bail spring cover
29	E24-8103	Bail spring cover screw
30	F01-4301	Bail trip plate
31	F48-2301	Bail trip lever
32	F48-2402	Bail trip cover
33	F38-5103	Bail trip cover screw
34	F19-7202	Oiled washer
35	F15-3301	Roller clutch
36	F21-2501	Roller clutch retainer
37	375-8507	Spacing sleeve A
38	F15-5101	Spacing sleeve B
39	F15-1201	Anti-reverse ratchet

Key

No.	Parts No.	Parts Name
40	F26-8501	Bearing washer
41	F15-1102	Bearing retainer
42	F21-2201	Bearing retainer screw
43	636-6401	Ball bearing B
44	F26-3101	Pinion washer
45	F16-2502	Pinion gear
46	F50-5801	Body assembly
47	L00-1801	Anti-reverse pawl screw
48	F15-1501	Anti-reverse pawl
49	F15-8301	Anti-reverse pawl collar
50	F15-1601	Anti-reverse pawl spring
51	E26-8701	Anti-reverse cam spring
52	F16-2809	Anti-reverse lever
53	E41-7101	Worm gear
54	F30-6602	Worm shaft
55	F02-4301	Oscillating slider
56	E19-1203	Oscillating pawl
57	E19-1301	Oscillating pawl bush
58	375-0801	Oscillating pawl washer
59	F24-4901	Oscillating slider cover
60	E15-0203	Oscillating slider cover screw
61	B53-6100	Worm shaft washer
62	F05-6901	Worm shaft collar
63	F08-7201	Shield plate
64	F08-7101	Pinion collar
65	F16-3903	Water shield
66	F16-4008	Rear cover
67	E24-8103	Rear cover screw
68	E30-6801	Ball bearing C
69	F00-7103	Drive gear
70	375-8501	Drive gear washer
71	637-5701	Ball bearing D
72	F17-6207	Side cover
73	E13-0501	Side cover screw A
74	F40-4801	Handle collar
75	363-8511	Handle screw
76	F50-6701	Handle cap
77	F50-9201	Handle assembly
78	E13-0503	Side cover screw B