


JUPITER-X3505T



Key No.	Parts No.	Parts Name
	2-9 F61-1801	SPOOL
	1 F32-9506	DRAG KNOB
	2 171-7701	DRAG WASHER RET
	3 F09-4901	KEY WASHER
	4 E13-6003	DRAG WASHER
	5 373-3603	EARED WASHER
	7 B07-5304	CLICK PAWL
	8 E40-3101	CLICK SPRING
	9 320-5901	CLICK RET
	10 F09-4701	SPOOL WASHER
	11 E46-2701	CLICK GEAR
	12 F61-9501	MAIN SHAFT
	13 F09-1301	OSC SLIDER
	14 352-1502	OSC SLIDER SCREW
	15 340-6602	ROTOR NUT
	16 F62-0304	ROTOR
	17 B67-9305	LINE ROLLER SCREW
	18 F61-9302	BAIL ARM
	19 E49-3501	BAIL ARM SCREW
	20 320-5901	BAIL ARM SCREW RET
	21 F44-6302	LINE ROLLER COLLAR
	22 F44-6202	LINE ROLLER WASHER
	23 F47-3401	LINE ROLLER BUSHING
	24 F45-4901	LINE ROLLER
	25 F61-9902	BAIL
	26 B84-2102	BAIL HOLDER SCREW
	27 E46-2101	BAIL TRIP LEVER
	28 F18-0007	TRIGGER LEVER

Key No.	Parts No.	Parts Name
	29 E36-9901	TRIGGER SPRING
	30 E37-0001	TRIGGER SCREW
	31 F12-8901	BAIL SPRING
	32 F31-4510	BAIL SPRING COVER
	33 E36-4201	BAIL SPRING COVER SCREW
	34 F31-4610	BAIL TRIP COVER
	35 E46-2001	SPRING HOLDER
	36 F24-8901	A/R RATCHET
	37 L03-6502	BALL BEARING
	38 E48-5201	PINION GEAR
	39 F61-1602	BODY
	40 E00-7101	A/R PAWL SCREW
	41 E46-1302	A/R PAWL
	42 E46-1201	A/R PAWL SPRING
	43 E03-7801	BEARING RET SCREW
	44 F38-5901	A/R CAM SPRING
	45 F08-5109	A/R LEVER
	46 F13-1601	OSC GEAR COLLAR
	47 E46-1501	OSC GEAR
	48 E46-1701	DRIVE GEAR
	49 373-7802	DRIVE GEAR WASHER
	50 F61-1702	SIDE COVER
	51 B83-5001	SIDE COVER SCREW A
	52 E15-8601	SIDE COVER SCREW B
	53 L01-1102	HANDLE
	54 B92-4902	HANDLE LOCK WASHER
	55 B92-5004	HANDLE LOCK SCREW