


PROCASTER-X103HLA



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	F87-6902	BRAKE ADJ KNOB	50	F86-5301	CLUTCH LEVER
2	F05-1701	BRAKE CLICK SPRING	51	F94-5001	CLUTCH LEVER SPRING
3	F96-7601	R/S PLT	52	F83-5401	CLUTCH LEVER WASHER
4	B84-2102	SET PLT SCREW	53	F83-5301	CLUTCH LEVER SCREW
5	374-9103	SPACER A	54	F92-3401	PINION GEAR
6	374-9105	SPACER B	55	E21-9701	BEARING RET B
7	F40-3701	BUSHING A	56	F05-5601	BALL BEARING B
9	F41-2301	BEARING RET A	57	F96-5902	L/S PLT
10	F87-6601	MAGNET HOLDER	58	351-1107	L/S PLT SCREW A
11-19	Z01-1740	SPOOL	59	F93-0201	PINION SHAFT
20	F92-3102	FRAME	60	B17-5503	SPOOL ADJ CAP METAL
21	F91-7002	REAR COVER	61	B17-5402	SPACER C
23	351-1101	REAR COVER SCREW	62	171-5201	O RING
24	320-5901	WORM SHAFT RET	63	F40-3002	CAST CONTROL CAP
25	F65-5501	WORM SHAFT WASHER	65	F45-6701	L/S PLT SCREW B
26	B71-5601	WORM SHAFT HOLDER	66	F64-7201	DRIVE SHAFT WASHER A
27	F90-5001	LEVEL WIND GUARD	67	B55-0301	DRIVE SHAFT BUSH
28	F96-7701	LINE GUIDE PAWL HOLDER	68	F83-5701	DRIVE SHAFT RET
29	121-4212	LINE GUIDE PAWL	69	F68-9501	CLUTCH TRIP PLT SPRING
30	F95-0200	LINE GUIDE WASHER	70	F21-1101	DRIVE SHAFT RET SCREW
31	F40-2801	PAWL CAP	71	F96-6101	DRIVE SHAFT
32	F93-2201	BUSHING B	72	F76-1701	A/R RATCHET
33	F93-3201	WORM SHAFT	73	F19-0101	DRIVE SHAFT WASHER B
34	B41-1701	DRIVE GEAR WASHER	74	F92-3501	DRIVE GEAR
35	F95-8401	DRIVE GEAR A	75	375-9405	DRAG WASHER A
36	F95-8501	DRIVE GEAR B	76	E20-0201	KEY WASHER
37	F92-3301	DRIVE GEAR SCREW	77	E42-5401	SPACING SLEEVE
38	F97-3201	STABILIZER BAR	78	F82-1301	GEAR SHAFT COLLAR
39	B86-4101	STABILIZER BAR RET	79	F58-0601	ROLLER CLUTCH
40	F91-7204	PALMING PLT	80	373-7810	DRAG WASHER B
41	F91-7102	FRONT PLT	82	150-8901	DRAG SPRING WASHER
42	F83-4701	BALL BEARING COLLAR	83	F11-8801	HANDLE COLLAR
43	B86-1702	BALL BEARING A	84	F40-3202	STAR DRAG
44	F92-3901	CLUTCH CAM	85	B43-3602	DRAG NUT
45	F83-4801	CLUTCH TRIP PLT	86	150-9001	FRICTION WASHER
46	F77-4603	CLUTCH TRIP PLT WASHER	87	F93-8401	HANDLE
47	320-5901	CLUTCH TRIP PLT RET	88	B43-3602	HANDLE NUT
48	F83-5801	YOKE	89	F05-4403	HANDLE NUT PLT
49	F58-8001	YOKE SPRING	91	351-1803	HANDLE NUT PLT SCREW