


# PROCYON 103HSD



| Key No. | Parts No. | Parts Name             | Key No. | Parts No. | Parts Name               |
|---------|-----------|------------------------|---------|-----------|--------------------------|
| 1       | F87-6906  | BRAKE ADJ KNOB         | 48      | F05-5601  | BALL BEARING B           |
| 2       | F05-1701  | BRAKE CLICK SPRING     | 49      | F87-5810  | R/S PLT                  |
| 3       | F87-6206  | L/S PLT                | 50      | F80-0501  | PINION SHAFT             |
| 4       | B84-2102  | SET PLT SCREW          | 51      | B17-5402  | SPOOL ADJ CAP METAL      |
| 5       | 374-9103  | SPACER A               | 52      | B17-5503  | SPACER C                 |
| 6       | 374-9105  | SPACER B               | 53      | 171-5201  | O RING                   |
| 7       | F40-3701  | BUSHING A              | 54      | F64-9803  | CAST CONTROL CAP         |
| 9       | F41-2301  | BEARING RET A          | 55      | B67-9304  | R/S PLT SCREW A          |
| 10      | F87-6601  | MAGNET HOLDER          | 57      | F93-8201  | R/S PLT SCREW B          |
| 11-19   | Z01-1740  | SPOOL                  | 63      | F64-7201  | DRIVE SHAFT WASHER       |
| 20      | F87-4002  | FRAME                  | 64      | B55-0301  | BUSHING B                |
| 21      | F87-4302  | CLUTCH LEVER PLT A     | 65      | F87-4701  | DRIVE SHAFT RET          |
| 22      | F87-4502  | CLUTCH LEVER           | 66      | F50-5701  | DRIVE SHAFT RET SCREW A  |
| 23      | F87-4202  | CLUTCH LEVER PLT B     | 67      | F21-1101  | DRIVE SHAFT RET SCREW B  |
| 24      | 320-5901  | WORM SHAFT RET         | 68      | G25-1201  | DRIVE SHAFT              |
| 25      | F65-5501  | WORM SHAFT WASHER      | 69      | F76-1701  | A/R RATCHET              |
| 26      | B71-5601  | WORM SHAFT HOLDER A    | 70      | F87-5601  | DRIVE GEAR A             |
| 27      | F90-5002  | LEVEL WIND GUARD       | 71      | G11-5401  | DRIVE GEAR B             |
| 28      | F87-5102  | LINE GUIDE             | 72      | F79-6101  | EARED WASHER             |
| 29      | 121-4212  | LINE GUIDE PAWL        | 73      | F79-6201  | DRAG WASHER A            |
| 30      | F95-0200  | LINE GUIDE WASHER      | 74      | F79-6301  | KEY WASHER A             |
| 31      | F40-2801  | PAWL CAP               | 75      | F96-7801  | DRAG WASHER B            |
| 32      | F90-5101  | WORM SHAFT HOLDER B    | 76      | B36-0303  | KEY WASHER B             |
| 33      | F87-5301  | WORM SHAFT             | 77      | G27-5901  | GEAR SHAFT COLLAR        |
| 34      | F42-8801  | CLUTCH TRIP PLT        | 78      | F58-0601  | ROLLER CLUTCH            |
| 35      | F87-7901  | CLUTCH TRIP PLT SPRING | 80      | B86-1702  | BALL BEARING C           |
| 36      | F87-5903  | FRONT PLT              | 81      | F36-6802  | BEARING WASHER           |
| 37      | F91-5601  | STABILIZER BAR         | 82      | 150-8901  | DRAG SPRING WASHER       |
| 38      | F87-6007  | PALMING PLT            | 83      | 373-7807  | SPACING SLEEVE           |
| 39      | F79-3401  | CLUTCH CAM WASHER      | 84      | F40-3201  | STAR DRAG                |
| 40      | B86-1702  | BALL BEARING A         | 85      | B43-3601  | DRAG NUT                 |
| 41      | F87-4801  | CLUTCH CAM SPRING      | 86      | 150-9001  | FRICTION WASHER          |
| 42      | F87-4401  | CLUTCH CAM             | 87      | G11-0102  | HANDLE                   |
| 43      | G25-1301  | PINION GEAR            | 88      | B43-3601  | HANDLE NUT               |
| 44      | F87-4901  | YOKE                   | 89      | F40-8406  | HANDLE NUT PLT           |
| 45      | G00-4401  | YOKE WASHER            | 90      | F03-2401  | CLICK LEAF SPRING        |
| 46      | F86-4101  | YOKE SPRING            | 91      | F02-8201  | CLICK LEAF SPRING HOLDER |
| 47      | E21-9701  | BEARING RET B          | 92      | F21-1103  | CLUTCH LEVER SCREW       |