


LAGUNA 500 / 1000



Key No.	Parts No.	Parts Name
1	E58-4201	DRAG KNOB
2	F66-7901	DRAG WASHER RET
3	F66-7801	KEY WASHER
4	F66-7701	DRAG WASHER
2-8	E58-2401	SPOOL
2-8	E58-4501	SPOOL (EXTRA)
6	F66-7601	CLICK PAWL
7	144-1211	CLICK SPRING
8	B86-4101	CLICK RET
9	F66-7000	SPOOL WASHER
10	F66-6302	MAIN SHAFT
11	E32-0601	OSC SUPPORT
12	E15-0201	OSC SUPPORT SCREW
13	342-4001	ROTOR NUT
14	E58-1301	ROTOR
15	E32-0201	BAIL SPRING
16	E58-1501	BAIL SPRING COVER
17	352-2501	BAIL SPRING COVER SCREW
18	G01-8601	LINE ROLLER SCREW
19	E58-1401	BAIL ARM
20	351-6101	BAIL ARM SCREW
21	F89-7101	LINE ROLLER WASHER
22	F62-5001	LINE ROLLER
23	G02-0801	BALL BEARING A
24	E58-1801	BAIL
25	E58-1601	BAIL TRIP LEVER
26	E58-1701	BAIL TRIP LEVER COVER
27	E58-0801	BEARING RET
28	E18-2801	BALL BEARING B

Key No.	Parts No.	Parts Name
29	F62-2301	CLUTCH CAM RET
30	E58-0701	CLUTCH CAM
31	B12-8701	CLUTCH CAM WASHER
32	E58-0601	SPACING SLEEVE
33	G22-0601	ROLLER CLUTCH
34	E18-2801	BALL BEARING C
35	E58-0501	PINION GEAR
36	E58-0101	BODY
37	F66-4501	A/R CAM SPRING
38	E58-0301	A/R LEVER
39	E58-1101	REAR COVER A
40	E58-1201	REAR COVER B
41	F98-9401	REAR COVER SCREW
42	F69-0801	BALL BEARING D
43	F66-6101	DRIVE GEAR
44	F66-6501	OSC SLIDER
45	375-8500	DRIVE GEAR WASHER
46	637-5701	BALL BEARING E
47	E58-1001	SIDE COVER
48	351-7801	SIDE COVER SCREW A
49	E58-2101	HANDLE
50	F02-0201	HANDLE WASHER
51	E03-5507	HANDLE SCREW
52	E49-2201	SIDE COVER SCREW B

SPECIAL PART FOR LA1000

Key No.	Parts No.	Parts Name
2-8	E58-2701	SPOOL
2-8	E58-4701	SPOOL (EXTRA)