

CL 200L, 202L SPARE PARTS LIST

KEY NO.	PARTS NAMES	PARTS NO.	200L	202L	KEY NO.	PARTS NAMES	PARTS NO.	200L	202L
100	MAIN BODY ASSY.	11100027111	•	•	701	DRIVE GEAR SHAFT ASSY.(MAMAL TIP)	1170100903001	•	•
105	WORM SHAFT BUSHING	11105003-01	•	•	702	PINION GEAR	1170201103002	•	•
105-1	WORM SHAFT BUSHING	11105004-01	•	•	703	LEVEL WIND GUARD	11703009-03	•	•
117	HANDLE NUT	14117001-03	•	•	704	STABILIZER BAR	11704008-03907	•	•
200	RIGHT SIDE PLATE	11200035-01001	•	•	705	WORM SHAFT GEAR	11705006-06	•	•
201	ANTI-REVERSE PAWL	11201008-06	•	•	706	IDLE GEAR	11706002-06	•	•
207	HOLD PLATE	11207017-03001	•	•	707	MEDIUM TRANSMISSION GEAR	11707008-11	•	•
211	ANTI-REVERSE PAWL PIN	11211003-03001	•	•	709	TRANSMISSION GEAR BUSHING	11709002-03	•	•
215	HOLD PLATE BUSHING	11215009-03001	•	•	710	LINE GUIDE ASSY.	1171000906	•	•
216	ANTI-REVERSE PAWL SPRING	11216001-06	•	•	712	WORM SHAFT	11712019-03	•	•
216-1	CLUTCH CAM SLIDER SPRING	11216002-06	•	•	713	PAWL CAP	11713001-03907	•	•
221	O RING	11221001-07	•	•	715	LINE GUIDE PAWL	11715003-06	•	•
300	LEFT SIDE PLATE	11300030-01001	•	•	800	CLUTCH CAM	11800002-02002	•	•
302	SPACER	11302002-06001	•	•	801	CLUTCH CAM SPRING	11801001-06	•	•
302-1	SPOOL SHAFT BUSHING	11302005-03	•	•	802	CLUTCH BAR	11802003-01	•	•
302-3	SPACER	11302006-03	•	•	804	CLUTCH CAM SLIDER (MAMAL TIP)	11804004-06	•	•
303	CLICK BUTTON	11303007-03907	•	•	804	CLUTCH CAM SLIDER (AUTO TIP)	11804005-06	•	•
304	CLICK PAWL	11304003-06	•	•	805	PINION GEAR YOKE	11805002-01	•	•
305	CLICK PAWL SPRING	11305001-01001	•	•	806	YOKE SPRING	11806001-06	•	•
311	SIDE PLATE COVERS	11311007-06001			9102	BALL BEARING	01081605-61		•
400	GRAPHITE SPOOL ASSY.	11400029-01001C	•	•	9106	BALL BEARING	01041104-61	•	•
401	CLICK GEAR	11401001-05002	•	•	9201	DRIVE GEAR SHAFT WASHER	028.1x12x0.5-6	•	•
500	DOUBLE HANDLE ASSY.	1150000504907	•	•	9201-1	DRIVE GEAR SHAFT WASHER	025.1x8x0.2-6	•	•
500	BALANCE WEIGHT HANDLE ASSY.	1150001304907	•	•	9202	LEVEL WIND GUARD WASHER	025.1x10.5x.2-6	•	•
516	HANDLE NUT HOLDER	11516001-01	•	•	9205	DRIVE GEAR WASHER	028.2x22x1-1	•	•
600	CAST CONTROL CAP	11600014-03001	•	•	9206	CLICK BUTTON WASHER	024.05x10x0.2-8	•	•
609	DRAG SPRING WASHER	11609003-05907	•	•	9301	RIGHT SIDE PLATE SCREW	03422.6x13-61	•	•
610	DRAG WASHER	11610004-006	•	•	9302	CLICK PAWL SCREW	03327.52.6x6-61	•	•
610-1	DRAG WASHER	11610003-006	•	•	9302-1	HOLD PLATE SCREW	03327.52.67.561	•	•
611	EARED WASHER	11611005-06	•	•	9307	HANDLE NUT HOLDER SCREW	03412.6x4-61	•	•
612	KEY WASHER	11612007-06001	•	•	9311	LEFT SIDE PLATE SCREW	03122.6x8-61	•	•

612-1	KEY WASHER	11612007-06003	•	•	9312	TRANSMISSION GEAR SCREW	03325.2x2x4.561	•	•
614	TENSION WASHER	11614001-06	•	•	9314	CLICK GEAR SCREW(GRAPHITE SOOL USED)	03222x4.5-61	•	•
615	STAR DRAG	11615003-01	•	•	9316	CLUTCH BAR SCREW	03414x5-617	•	•
617	DRIVE GEAR SHAFT BUSHING	11617005-03	•	•	9319	CLUTCH CAM SCREW	03312x5-61	•	•
617	DRIVE GEAR SHAFT BUSHING	11617006-01		•	9401	DRIVE GEAR SHAFT "E" RETAINER	11900001-06	•	
700	DRIVE GEAR	11700008-03002	•		9404	WORM SHAFT "E" RETAINER	12900001-06		•
701	DRIVE GEAR SHAFT ASSY.(AUTO TIP)	1170100903001A	•	•					