



SHIMANO

1987 REPAIR MANUAL

Shimano American Corporation, One Shimano
Irvine, CA 92718

TO ORDER:

This reel belongs to the "Bantam" series.
Please order parts using the abbreviation
"BNT" and the part number.



EXPLODED PARTS VIEW BGX 1550

PARTS LIST

PART # DESCRIPTION

1. Handle Nut Plate Screw
2. Handle Nut
6. Friction Washer "A"
9. Cast Control Spacer
11. Right Side Plate Screw
14. Friction Washer "B"
15. Drag Spring Washer
16. Friction Washer "C"
32. Bearing Retainer
36. Stabilizer Bar Screw "A"
40. Level Wind Guard
42. Line Guide Pawl
44. Stabilizer Bar
45. Worm Bearing "B"
60. Spacer (optional)
133. Worm Shaft Retainer
151. Pawl Cap
162. Drive Shaft Retainer
170. Anti-Reverse Pawl
184. Magnet Retainer Lock
188. O Ring
191. Left Side Plate Screw
192. Stabilizer Bar Screw "B"

PART # DESCRIPTION

244. Bushing "B"
265. Spacer (optional)
268. Drive Shaft Washer "A"
277. Bearing Spacer "B"
311. Magnet Retainer
330. Handle Nut Plate
335. Bearing Washer "A"
340. Switch Spring
341. Switch Spring Lock
345. Drive Shaft Washer "B"
352. Yoke
354. Retractor Spring
356. Worm Bearing "A"
357. Line Guide
365. Magnetic Control Dial
398. Anti-Reverse Switch
405. Retractor Guide
423. Yoke Spring
458. Bushing "A"
459. Retractor Guide Screw
463. Spool
464. Bearing Spacer

PART # DESCRIPTION

467. Worm Shaft
470. Bushing "C"
483. Handle Assembly
484. Star Drag
486. Right Side Plate Cover
487. Cast Control Cap
488. Clutch Button Attachment
489. Key Washer "A"
490. Drag Washer
491. Drive Gear
492. Key Washer "B"
493. Anti-Reverse Ratchet
494. Drive Shaft
495. Idle Gear
496. Drive Shaft Washer "C"
497. Pinion Gear
502. Level Wind Protector
523. Right Side Plate
524. Set Plate Assembly
525. Frame
526. Left Side Plate
527. Thumb Rest