


SHIMANO

1987 REPAIR MANUAL

Shimano American Corporation, One Shimano
Irvine, CA 92718



EXPLODED PARTS VIEW TRITON[®] SPEEDMASTER[™] TSM III

PARTS LIST

PART #	DESCRIPTION	PART #	DESCRIPTION	PART #	DESCRIPTION
1.	Handle Nut Plate Screw	77.	Handle Assembly	97.	Key Washer "C"
2.	Handle Nut Plate	78.	Handle Washer	98.	Eared Washer "B"
14.	Lock Washer	79.	Star Drag	99.	Drive Gear
16.	Clutch Spring	80.	Star Drag Washer	100.	Drive Shaft Washer
31.	Drive Shaft Bushing	81.	Right Side Plate Screw (A)	101.	Anti-Reverse Ratchet
32.	Spacer	82.	Spool Shaft Bushing	102.	Drive Shaft
33.	Drive Shaft Retainer	83.	Right Side Plate	103.	Pinion Gear
37.	Anti-Reverse Pawl	84.	Cast Control Cap	104.	Yoke Spring
39.	Anti-Reverse Pawl Spring	85.	Spacer	105.	Yoke
41.	Yoke Plate	86.	Spool Tension Spring	106.	Frame
52.	Ball Bearing	87.	Clutch Lever Screw	107.	Line Guard
54.	Click Gear	88.	Clutch Lever	108.	Line Guard Screw
58.	Spacer "B"	89.	Clutch Cam	109.	Right Side Plate Screw (B)
62.	Click Pawl Retainer	90.	Ball Bearing	110.	Spool
63.	Click Pawl	91.	Bearing Thrust Washer	111.	Click Gear Retainer
65.	Spacer A	92.	Drag Spring Washer	112.	Ball Bearing
67.	Click Spring	93.	Key Washer "F"	113.	Left Side Plate
68.	Click Spring Screw	94.	Drag Washer "I"	114.	Left Side Plate Screw
70.	Spacer "B"	95.	Eared Washer "E"	115.	Click Button
76.	Handle Nut	96.	Drag Washer "D"	138.	"O" Ring