



1988 REPAIR MANU

Shimano American Corporation, One Shimano
Irvine, CA 92



PART #	DESCRIPTION	PART #	DESCRIPTION	PART #	DESCRIPTION
RD 0013	(Trip) Lever Spring	RD 0884	Anti-Reverse Ratchet	RD 1429	Bail Assembly
RD 0018	Line Roller	RD 0940	Bail Trip Cam Screw	RD 1430	Bail Trip Cover
RD 0023	Trip Lever Spacer	RD 0948	Bail Trip Cover Screw	RD 1431	Bail Spring Cover
RD 0026	Ball Bearing	RD 1004	Bushing A	RD 1432	Bail Arm
RD 0041	Drive Gear Washer	RD 1007	Lock Washer Retainer	RD 1433	Bail Trip Lever
RD 0049	Lock Washer	RD 1008	Handle Lock Washer	RD 1434	Pinion Spacer
RD 0053	Anti-Reverse Cam Spring	RD 1083	Slider Retainer Screw	RD 1435	Anti-Reverse Lock Out
RD 0071	Rotor Nut	RD 1302	Line Roller Screw	RD 1436	Body
RD 0345	Anti-Reverse Lever Screw	RD 1418	Drag Knob	RD 1437	Pinion Gear
RD 0419	Bushing Washer (B)	RD 1419	Drag Washers Retainer	RD 1438	Anti-Reverse Pawl
RD 0539	Anti-Reverse Pawl Spring	RD 1420	Key Washer	RD 1439	Drive Gear
RD 0540	Anti-Reverse Pawl Screw	RD 1421	Drag Washer	RD 1440	Oscillating Arm
RD 0543	Side Cover Screw (B)	RD 1422	Eared Washer	RD 1441	Side Cover
RD 0647	Nut Lock Screw	RD 1423	Drag Spring	RD 1442	Handle Screw-Cap
RD 0781	Bail Spring	RD 1424	Spool Assembly	RD 1443	Oscillating Block
RD 0784	Line Roller Washer	RD 1425	Main Shaft	RD 1444	Anti-Reverse Cam
RD 0787	Nut Lock Screw	RD 1426	Spool Washer	RD 1445	Anti-Reverse Lever
RD 0792	Bearing Retainer Screw	RD 1427	Spool Support	RD 1446	Handle Assembly
RD 0795	Bushing B	RD 1428	Rotor		