


SHIMANO

1988 REPAIR MANUAL

Shimano American Corporation, One Shimano I
Irvine, CA 927



EXPLODED PARTS VIEW

TRITON *SpeedMaster* TSM II FS
with *Fightin' Star*™

PARTS LIST

PART # DESCRIPTION

TGT 0014	Lock Washer
TGT 0024	Eared Washer "E"
TGT 0026	Eared Washer "B"
TGT 0031	Drive Shaft Bushing
TGT 0032	Spacer
TGT 0033	Drive Shaft Retainer
TGT 0037	Anti-Reverse Pawl
TGT 0039	Anti-Reverse Pawl Spring
TGT 0041	Yoke Plate
TGT 0054	Click Gear
TGT 0058	Spacer "B"
TGT 0062	Click Pawl Retainer
TGT 0063	Click Pawl
TGT 0065	Spacer A
TGT 0067	Click Spring
TGT 0068	Click Spring Screw
TGT 0070	Spacer B
TGT 0076	Handle Nut
TGT 0087	Clutch Lever Screw
TGT 0090	Ball Bearing
TGT 0091	Bearing Thrust Washer
TGT 0092	Drag Spring Washer
TGT 0104	Yoke Spring

PART # DESCRIPTION

TGT 0109	Right Side Plate Screw (B)
TGT 0111	Click Gear Retainer
TGT 0142	Handle Nut Plate Screw
TGT 0145	Friction Washer
TGT 0146	Pre-Set Dial
TGT 0147	Pre-Set Spring
TGT 0148	Pre-Set Nut
TGT 0149	Strike
TGT 0150	Strike Spring
TGT 0151	Strike Spacer
TGT 0152	Strike Ball
TGT 0153	Star Drag
TGT 0154	Drive Shaft Cam
TGT 0157	Drag Washer "G"
TGT 0158	Drag Washer "I"
TGT 0159	Key Washer "F"
TGT 0161	Drive Shaft Washer
TGT 0162	Anti-Reverse Ratchet
TGT 0163	Drive Shaft
TGT 0178	Handle Nut Plate
TGT 0179	Handle Assembly
TGT 0180	Cast Control Cap
TGT 0181	Drag Spring Washer

PART # DESCRIPTION

TGT 0182	Cast Control Spacer
TGT 0183	Felt Washer
TGT 0184	Ball Bearing
TGT 0185	O Ring
TGT 0186	Bushing Screw
TGT 0187	Right Side Plate Screw (A)
TGT 0188	Right Side Plate
TGT 0189	Clutch Lever
TGT 0190	Clutch Spring
TGT 0191	Clutch Cam
TGT 0192	Side Plate Bushing
TGT 0193	Key Washer "F2"
TGT 0194	Drive Gear
TGT 0195	Pinion Gear
TGT 0196	Yoke
TGT 0197	Frame
TGT 0198	Spool
TGT 0199	Left Side Plate
TGT 0200	Left Side Plate Screw
TGT 0201	Click Button
TGT 0202	Rod Clamp
TGT 0203	Rod Clamp Bolt