


SHIMANO

1988 REPAIR MANUAL

Shimano American Corporation, One Shimano
Irvine, CA 92



EXPLODED PARTS VIEW

TRITON *SpeedMaster* TSM III FS
with *Fightin' Star*™

PARTS LIST

PART # DESCRIPTION

TGT 0014 Lock Washer
TGT 0016 Clutch Spring
TGT 0031 Drive Shaft Bushing
TGT 0033 Drive Shaft Retainer
TGT 0037 Anti-Reverse Pawl
TGT 0039 Anti-Reverse Pawl Spring
TGT 0041 Yoke Plate
TGT 0052 Ball Bearing
TGT 0054 Click Gear
TGT 0058 Spacer "B"
TGT 0062 Click Pawl Retainer
TGT 0063 Click Pawl
TGT 0065 Spacer A
TGT 0067 Click Spring
TGT 0068 Click Spring Screw
TGT 0070 Spacer B
TGT 0076 Handle Nut
TGT 0081 Right Side Plate Screw (A)
TGT 0082 Spool Shaft Bushing
TGT 0083 Right Side Plate
TGT 0084 Cast Control Cap
TGT 0085 Spacer

PART # DESCRIPTION

TGT 0086 Spool Tension Spring
TGT 0087 Clutch Lever Screw
TGT 0088 Clutch Lever
TGT 0089 Clutch Cam
TGT 0090 Ball Bearing
TGT 0091 Bearing Thrust Washer
TGT 0092 Drag Spring Washer
TGT 0093 Key Washer "F"
TGT 0094 Drag Washer "D"
TGT 0095 Eared Washer "E"
TGT 0096 Drag Washer "I"
TGT 0097 Key Washer "C"
TGT 0098 Eared Washer "B"
TGT 0099 Drive Gear
TGT 0100 Drive Shaft Washer
TGT 0101 Anti-Reverse Ratchet
TGT 0103 Pinion Gear
TGT 0104 Yoke Spring
TGT 0105 Yoke
TGT 0107 Line Guard
TGT 0108 Line Guard Screw
TGT 0109 Right Side Plate Screw (B)

PART # DESCRIPTION

TGT 0110 Spool
TGT 0111 Click Gear Retainer
TGT 0112 Ball Bearing
TGT 0113 Left Side Plate
TGT 0114 Left Side Plate Screw
TGT 0115 Click Button
TGT 0145 Friction Washer
TGT 0146 Pre-Set Dial
TGT 0147 Pre-Set Spring
TGT 0148 Pre-Set Nut
TGT 0149 Strike
TGT 0150 Strike Spring
TGT 0151 Strike Spacer
TGT 0152 Strike Ball
TGT 0153 Star Drag
TGT 0170 Handle Nut Plate Screw
TGT 0171 Handle Nut Plate
TGT 0172 Handle Assembly
TGT 0173 Drive Shaft Cam
TGT 0174 Drive Shaft
TGT 0175 Frame
TGT 0176 Spacer