


**EXPLODED PARTS VIEW**





TRITON GRAPHITE CONSTRUCTION
BAITRUNNER Plus 6500
US

SHIMANO®

1989 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718

※Please look here for (89) mark here



※If your reel does not have an (89) mark molded on the top of the reel foot as indicated in the exploded view, please use the parts view

in the box to order these specific parts. All other parts numbers are as shown in the exploded view.

PARTS LIST**PART # DESCRIPTION**

BR 0020 Bail Trip Cover Screw
BR 0045 Anti-Reverse Lever
BR 0046 Anti-Reverse Lever Screw
BR 0054 Lever Shaft Retainer
BR 0055 Shaft Retainer Screw
BR 0057 Clutch Plate Screw
BR 0058 Side Cover Screw A
BR 0065 Dial Click Screw
BR 0066 Pawl Guide Screw
BR 0074 Clutch Cam Spacer B
BR 0079 Baitrunner Click Spring
BR 0080 Side Cover Screw B
BR 0086 Free Spool Tension Spring
BR 0088 Tension Spring Washer "B"
BR 0092 Baitrunner Lever Screw
BR 0093 Lock Washer
BR 0112 Trip Lever Guide
BR 0113 Lever Spring
BR 0117 "E" Lock
BR 0121 Lock Washer
BR 0127 Pinion Spacer
BR 0129 Ball Bearing
BR 0137 Ball Bearing
BR 0143 Clutch Spring
BR 0144 Clutch Pawl Spring
BR 0146 Handle Lock Washer
BR 0150 Baitrunner Pawl Guide
BR 0151 Baitrunner Pawl Spring
BR 0153 Dial Retainer
BR 0160 Clutch Arm
BR 0165 Click Gear
BR 0166 Eared Washer "BFS"
BR 0167 Free Spool Tension Screw
BR 0168 Dial Spacer
BR 0169 Baitrunner Tension Dial
BR 0175 Drag Washers Retainer
BR 0177 Drag Washer 1

PART # DESCRIPTION

BR 0178 Eared Washer
BR 0179 Eared Washer 2
BR 0182 Spool Washer
BR 0183 Rotor Nut
BR 0184 Multi Purpose Screw
BR 0185 Rotor Nut Lock Plate
BR 0186 Rotor
BR 0187 Bail Trip Slide Cam
BR 0188 Bail Trip Lever
BR 0190 Bail Trip Cover
BR 0191 Line Roller
BR 0192 Bail Spring
BR 0193 Bail Spring Cover
BR 0194 Line Roller Screw
BR 0195 Bail Arm
BR 0196 Line Roller Washer
BR 0197 Bail Arm Screw
BR 0198 Anti-Reverse Pawl Spring
BR 0199 Anti-Reverse Spring Holder
BR 0200 Anti-Reverse Ratchet
BR 0201 Bearing Retainer
BR 0202 Pinion Gear
BR 0204 Anti-Reverse Pawl
BR 0207 Pinion Gear Bushing
BR 0208 Anti-Reverse Cam
BR 0209 Anti-Reverse Cam Spring
BR 0211 Drive Gear Spacer
BR 0212 Drive Gear Washer
BR 0213 "C" Lock
BR 0214 Baitrunner Ratchet
BR 0215 Ratchet Spacer
BR 0217 Handle Lock Screw
BR 0218 Dial Click
BR 0219 Baitrunner Pawl
BR 0220 Oscillating Gear Bushing
BR 0221 Oscillating Gear
BR 0222 Oscillating Slider

PART # DESCRIPTION

BR 0223 "C" Lock
BR 0225 Clutch Cam
BR 0226 Clutch Cam Spacer A
BR 0227 Clutch Plate Assembly
BR 0228 Baitrunner Lever Arm (L)
BR 0229 Free Spool Tension Shaft
BR 0231 Baitrunner Lever Arm (R)
BR 0232 Baitrunner Lever Bridge
BR 0233 Handle Assembly
BR 0234 Handle Lock Spacer
BR 0235 Handle Lock Ring
BR 0278 Nut Lock Screw
BR 0386 Anti-Reverse Pawl Screw
BR 0451 Fightin' Drag Knob
BR 0452 Key Washer
BR 0453 Spool Assembly
BR 0454 Main Shaft
BR 0455 Bail Assembly
BR 0457 Body
BR 0458 Side Cover
BR 0636 Seal Plate Screw
BR 0662 Lever Spring
BR 0667 Free Spool Tension Washer (A)
BR 0668 Free Spool Tension Washer (B)
BR 0688 Seal Plate
BR 0692 Line Roller Spacer
BR 0693 Line Roller Bushing
BR 0695 Line Roller Screw
BR 0696 Fightin' Drag Knob
BR 0697 Spool Assembly
BR 0698 Rotor
BR 0699 Bail Assembly
BR 0700 Line Roller Washer
BR 0710 Handle Screw Cap
BR 0716 Drive Gear
BR 0717 Handle Assembly