


**SOLSTACE  
1000R 91**

TO ORDER: USE RD PREFIX  
WITH PART NUMBER

**PARTS LIST**

| RD #  | DESCRIPTION                    | RD # | DESCRIPTION                  | RD # | DESCRIPTION                 |
|-------|--------------------------------|------|------------------------------|------|-----------------------------|
| 0041  | Drive Gear Washer              | 1362 | Drag Programmer              | 2293 | Drive Gear Bushing          |
| 0064  | Click Gear                     | 1397 | Fightin' DragII Lever        | 2294 | Drive Gear                  |
| 0071  | Rotor Nut                      | 1442 | Handle Screw Cap             | 2298 | Spacer                      |
| 0345  | Anti-Reverse Lever Screw       | 1504 | Bail Spring Cover Screw      | 2299 | Oscillating Slider Bushing  |
| 0543  | Side Cover Screw               | 1506 | Multi Purpose Screw          | 2300 | Oscillating Pawl            |
| 0544  | Drag Washer "Cz" (white)       | 1509 | Bail Spring                  | 2305 | Main Shaft                  |
| 0549  | Eared Washer "B"               | 1888 | Anti-Reverse Lock Out Spring | 2306 | Pinion Gear                 |
| 0551  | "O" Ring                       | 1890 | Bushing Washer               | 2307 | Worm Shaft                  |
| 0553  | Hold Click Spring              | 1891 | Bearing Retainer Screw       | 2309 | Slider Retainer Screw       |
| 0555A | Fightin' Pressure Screw Washer | 1974 | Drag Coil Spring             | 2310 | Oscillating Slider Retainer |
| 0560  | Lever Hold Spring              | 2271 | Quick-Fire II Trigger        | 2311 | Oscillating Slider          |
| 0562  | Drag Programmer Screw          | 2272 | Rotor Side Cover             | 2313 | Drag Ckucj                  |
| 0773  | Handle Knob                    | 2275 | Bail Spring Guide (B)        | 2314 | Pressure Screw              |
| 0774  | Handle Knob Screw              | 2277 | Bail Spring Cover            | 2315 | Lever Click Gear            |
| 0784  | Line Roller Washer             | 2278 | Bail Trip Lever              | 2380 | Drag Shaft                  |
| 0787  | Nut Lock Screw                 | 2279 | Anti-Reverse Ratchet         | 2852 | Handle Screw Lock           |
| 0930  | Ball Bearing                   | 2280 | Anti-Reverse Lock Out        | 2856 | Bail Spring Guide (A)       |
| 0940  | Bail Trip Cam Screw            | 2281 | Bearing Retainer             | 2857 | Trigger Cam                 |
| 0949  | Trigger Screw                  | 2283 | Anti-Reverse Pawl Screw      | 2858 | Bail Arm                    |
| 1008  | Handle Lock Washer             | 2284 | Anti-Reverse Pawl            | 2905 | Spool Assembly              |
| 1021  | Handle Assembly                | 2285 | Anti-Reverse Pawl Spring     | 3103 | Rotor                       |
| 1038  | Si Ceramic Roller              | 2286 | Anti-Reverse Cam             | 3125 | Deag Click Screw            |
| 1302  | Line Roller Screw              | 2287 | Anti-Reverse Cam Spring      | 3136 | Bail Assembly               |
| 1355  | Drag Washer "Cz" (white)       | 2288 | Worm Bearing                 | 3137 | Side Cover                  |
| 1356  | Eared Washer "Bz"              | 2290 | Idle Gear                    | 3138 | Body                        |
| 1360  | Fightin' Pressure Screw        | 2292 | Anti-Reverse Lever           |      |                             |