

'94 SO 1000FA

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	3455	Spool Washer	3659	Anti-Reverse Pawl Spring
0041	Drive Gear Washer	3471	Anti-Reverse Cam Spring	3660	Anti-Reverse Cam
0071	Rotor Nut	3645	Drag Knob	3661	Anti-Reverse Lever Assembly
0787	Nut Lock Screw	3646	Main Shaft	3662	Drive Gear
0792	Bearing Retainer Screw	3647	Rotor	3663	Oscillating Gear
0930	Ball Bearing	3648	Quick-Fire II Trigger Assembly	3664	Oscillating Slider
1427	Spool Support	3649	Line Roller	3665	Slider Retainer Screw
1504	Bail Spring Cover Screw	3650	Bail Assembly	3666	Side Cover Screws
1506	Bail Trip Leve Screw	3651	Bail Spring Guide(A)	3668	Handle Screw Cap Assembly
1890	Bushing Washer	3652	Bail Spring Guide(B)	3669	Handle Assembly
2280	Anti-Reverse Lock Out	3653	Bail Spring Cover	3869	Anti-Reverse Lock Out Spring
2283	Anti-Reverse Pawl Screw	3654	Counterbalance Cover	4051	Bail Spring
2857	Trigger Cam	3655	Cover Screw	4163	Line Roller Bushing
3400	Bail Trip Lever	3656	Anti-Reverse Ratchet	4191	Body Assembly
3447	Spool Assembly(aluminum)	3657	Pinion Gear		
3450	Spool Assembly(graphite)	3658	Anti-Reverse Pawl		

(051208)