



# SYNCOPATE

## 1000 94

'94 SC 1000F

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	3450	Spool Assembly (graphite)	3664	Oscillating Slider
0041	Drive Gear Washer	3455	Spool Washer	3665	Slider Retainer Screw
0071	Rotor Nut	3471	Anti-Reverse Cam Spring	3668	Handle Screw Cap Assembly
0540	Bail Trip Lever Screw	3645	Drag Knob	3669	Handle Assembly
0787	Nut Lock Screw	3646	Main Shaft	3700	Rotor
0792	Bearing Retainer Screw	3649	Line Roller	3701	Bail Assembly
1427	Spool Support	3651	Bail Spring Guide (A)	3702	Bail Spring Cover
1890	Bushing Washer	3652	Bail Spring Guide (B)	3703	Counterbalance Cover
1891	Bail Spring Cover Screw	3656	Anti-Reverse Ratchet	3704	Side Cover Screws
2280	Anti-Reverse Lock Out	3657	Pinion Gear	3869	Anti-Reverse Lock Out Spring
2283	Anti-Reverse Pawl Screw	3658	Anti-Reverse Pawl	4051	Bail Spring
2293	Drive Gear Bushing	3659	Anti-Reverse Pawl Spring	4160	Trigger Cam
3394	Quick-Fire II Trigger Assembly	3660	Anti-Reverse Cam	4163	Line Roller Bushing
3400	Bail Trip Lever	3661	Anti-Reverse Lever Assembly	4188	Body Assembly
3402	Cover Screw	3662	Drive Gear		
3447	Spool Assembly (aluminum)	3663	Oscillating Gear		

(051208)