



# SYNCOPATE 4000

'94 SC 4000F

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	3649	Line Roller	3693	Anti-Reverse Cam
0041	Drive Gear Washer	3661	Anti-Reverse Lever Assembly	3694	Drive Gear
0071	Rotor Nut	3665	Slider Retainer Screw	3695	Oscillating Gear
0540	Multi Purpose Screw	3668	Handle Screw Cap Assembly	3696	Oscillating Slider
0787	Nut Lock Screw	3676	Drag Knob	3699	Handle Assembly
0792	Bearing Retainer Screw	3677	Main Shaft	3710	Rotor
1511	Lever Spring	3681	Bail Spring Guide (A)	3711	Bail Assembly
1520	Anti-Reverse Cam Spring	3682	Bail Spring	3712	Bail Spring Cover
2293	Drive Gear Bushing	3683	Bail Spring Guide (B)	3713	Counterbalance Cover
2516	Spool Support	3685	Bail Trip Lever	3714	Side Cover Screws
2541	Anti-Reverse Pawl Screw	3687	Anti-Reverse Ratchet	3869	Anti-Reverse Lock Out Spring
3402	Cover Screw	3688	Anti-Reverse Lock Out	4161	Trigger Cam
3416	Quick-Fire II Trigger Assembly	3689	Bushing Washer	4163	Line Roller Bushing
3449	Spool Assembly (aluminum)	3690	Pinion Gear	4190	Body Assembly
3452	Spool Assembly (graphite)	3691	Anti-Reverse Pawl		
3503	Spool Washer	3692	Anti-Reverse Pawl Spring		

(051208)