

'94 SI 1000RA

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	3650	Bail Assembly	3746	Oscillating Slider Retainer
0041	Drive Gear Washer	3651	Bail Spring Guide (A)	3747	Slider Retainer Screw
0071	Rotor Nut	3652	Bail Spring Guide (B)	3748	Drag Shaft
0544	Drag Washer "C"(cloth)	3653	Bail Spring Cover	3749	Drag Washer "C"(white)
0787	Nut Lock Screw	3654	Counterbalance Cover	3750	Eared Washer "B"
0792	Bearing Retainer Screw	3655	Cover Screw	3751	Drag Washer "C"(blue)
1504	Bail Spring Cover Screw	3656	Anti-Reverse Ratchet	3752	Key Washer "A"
1506	Bail Trip Lever Screw	3658	Anti-Reverse Pawl	3753	Drag Coil Spring
1890	Bushing Washer	3659	Anti-Reverse Pawl Spring	3754	Drag Spring Washer
2280	Anti-Reverse Lock Out	3660	Anti-Reverse Cam	3755	Pressure Screw
2283	Anti-Reverse Pawl Screw	3663	Oscillating Gear	3756	Drag Knob Spacer
2293	Drive Gear Bushing	3668	Handle Screw Cap Assembly	3757	Drag Knob
2857	Trigger Cam	3669	Handle Assembly	3758	Drag Knob Screw
3125	Drag Click Screw	3739	Main Shaft	3759	Side Cover Screws
3400	Bail Trip Lever	3740	Pinion Gear	3869	Anti-Reverse Lock Out Spring
3441	Spool Assembly	3741	Anti-Reverse Lever Assembly	4051	Bail Spring
3471	Anti-Reverse Cam Spring	3742	Drive Gear	4163	Line Roller Bushing
3647	Rotor	3743	Hold Click Spring	4166	Body Assembly
3648	Quick-Fire II Trigger Assembly	3744	Drag Click		
3649	Line Roller	3745	Oscillating Slider		

(051126)