



SIDESTAB 4000

'94 SI 4000RA

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	2861	Trigger Cam	3693	Anti-Reverse Cam
0041	Drive Gear Washer	3125	Drag Click Screw	3694	Drive Gear
0071	Rotor Nut	3443	Spool Assembly	3695	Oscillating Gear
0111	Drag Coil Spring	3649	Line Roller	3699	Handle Assembly
0452	Drag Spring Washer	3655	Cover Screw	3741	Anti-Reverse Lever Assembly
0540	Bearing Retainer Screw	3668	Handle Screw Cap Assembly	3747	Slider Retainer Screw
0787	Nut Lock Screw	3678	Rotor	3762	Main Shaft
0826	Key Washer "A"	3679	Quick-Fire II Trigger Assembly	3763	Pinion Gear
1506	Multi Purpose Screw	3680	Bail Assembly	3764	Hold Click Spring
1511	Lever Spring	3681	Bail Spring Guide (A)	3765	Drag Click
1520	Anti-Reverse Cam Spring	3682	Bail Spring	3766	Oscillating Slider
2016	Drag Washer "H"(cloth)	3683	Bail Spring Guide (B)	3767	Oscillating Slider Retainer
2108	Eared Washer "B"	3684	Bail Spring Cover	3768	Drag Knob Spacer
2257	Drag Washer "H"(blue)	3685	Bail Trip Lever	3769	Drag Knob
2293	Drive Gear Bushing	3686	Counterbalance Cover	3770	Side Cover Screws
2346	Drag Washer "C"(cloth)	3687	Anti-Reverse Ratchet	3869	Anti-Reverse Lock Out Spring
2432	Drag Shaft	3688	Anti-Reverse Lock Out	4163	Line Roller Bushing
2433	Pressure Screw	3689	Bushing Washer	4168	Body Assembly
2458	Drag Knob Screw	3691	Anti-Reverse Pawl		
2541	Anti-Reverse Pawl Screw	3692	Anti-Reverse Pawl Spring		