



SPIREX 4000

'94 SR 4000F

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	3449	Spool Assembly (aluminum)	3693	Anti-Reverse Cam
0041	Drive Gear Washer	3452	Spool Assembly (graphite)	3694	Drive Gear
0071	Rotor Nut	3503	Spool Washer	3695	Oscillating Gear
0540	Multi Purpose Screw	3661	Anti-Reverse Lever Assembly	3696	Oscillating Slider
0787	Nut Lock Screw	3665	Slider Retainer Screw	3720	Line Roller
0792	Bearing Retainer Screw	3676	Drag Knob	3731	Rotor
0930	Ball Bearing	3677	Main Shaft	3732	Bail Assembly
1511	Lever Spring	3681	Bail Spring Guide (A)	3733	Bail Spring
1520	Anti-Reverse Cam Spring	3683	Bail Spring Guide (B)	3734	Bail Spring Cover
2516	Spool Support	3685	Bail Trip Lever	3735	Counterbalance Cover
2541	Anti-Reverse Pawl Screw	3687	Anti-Reverse Ratchet	3736	Side Cover Screws
3304	Bearing Spacer	3688	Anti-Reverse Lock Out	3738	Double Paddle Handle Assembly
3307	Line Roller Bushing	3689	Bushing Washer	3869	Anti-Reverse Lock Out Spring
3402	Cover Screw	3690	Pinion Gear	4161	Trigger Cam
3406	Handle Screw Cap Assembly	3691	Anti-Reverse Pawl	4196	Body Assembly
3416	Quick-Fire II Trigger Assembly	3692	Anti-Reverse Pawl Spring		

(051208)