



## '94 SR 4000R

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	3125	Drag Click Screw	3733	Bail Spring
0041	Drive Gear Washer	3304	Bearing Spacer	3734	Bail Spring Cover
0071	Rotor Nut	3307	Line Roller Bushing	3735	Counterbalance Cover
0540	Multi Purpose Screw	3402	Cover Screw	3738	Double Paddle Handle Assembly
0579	Eaerd Washer "B"	3406	Handle Screw Cap Assembly	3741	Anti-Reverse Lever Assembly
0586	Fightin' Pressure Screw Washer	3416	Quick-Fire II Trigger Assembly	3747	Slider Retainer Screw
0787	Nut Lock Screw	3443	Spool Assembly (aluminum)	3762	Main Shaft
0930	Ball Bearing	3446	Spool Assembly (graphite)	3763	Pinion Gear
1370	Lever Click Gaer	3681	Bail Spring Guide (A)	3764	Hold Click Spring
1371	Fightin' Pressure Screw	3683	Bail Spring Guide (B)	3765	Drag Click
1511	Lever Spring	3685	Bail Trip Lever	3766	Oscillating Slider
1520	Anti-Reverse Cam Spring	3687	Anti-Reverse Ratchet	3767	Oscillating Slider Retainer
2016	Drag Washer "H"(cloth)	3688	Anti-Reverse Lock Out	3768	Drag Programmer Spacer
2017	Drag Coil Spring	3689	Bushing Washer	3790	Pressure Screw Assembly
2257	Drag Washer "H"(blue)	3691	Anti-Reverse Pawl	3791	Fightin' Drag Lever
2346	Drag Washer "C"(cloth)	3692	Anti-Reverse Pawl Spring	3792	Lever Hold Spring
2347	Click Gear	3693	Anti-Reverse Cam	3793	Drag Programmer
2348	Drag Washer "C"(blue)	3694	Drive Gear	3794	Drag Programmer Screw
2349	Eaerd Washer "Bf"	3695	Oscillating Gear	3795	Side Cover Screws
2350	Drag Shaft	3720	Line Roller	3869	Anti-Reverse Lock Out Spring
2351	Drag Spring Washer	3731	Rotor	4161	Trigger Cam
2541	Anti-Reverse Pawl Screw	3732	Bail Assembly	4174	Body Assembly