



TX

1000

94

'94 TX 1000F

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD.No.	PARTS NAMES
0026	Ball Bearing	3455	Spool Washer	3658	Anti-Reverse Pawl
0041	Drive Gear Washer	3471	Anti-Reverse Cam Spring	3659	Anti-Reverse Pawl Spring
0071	Rotor Nut	3645	Drag Knob	3660	Anti-Reverse Cam
0787	Nut Lock Screw	3646	Main Shaft	3661	Anti-Reverse Lever Assembly
0792	Bearing Retainer Screw	3647	Rotor	3662	Drive Gear
1427	Spool Support	3648	Quick-Fire II Trigger Assembly	3663	Oscillating Gear
1504	Bail Spring Cover Screw	3649	Line Roller	3664	Oscillating Slider
1506	Bail Trip Lever Screw	3650	Bail Assembly	3665	Slider Retainer Screw
1890	Bushing Washer	3651	Bail Spring Guide (A)	3666	Side Cover Screws
2280	Anti-Reverse Lock Out	3652	Bail Spring Guide (B)	3668	Handle Screw Cap Assembly
2283	Anti-Reverse Pawl Screw	3653	Bail Spring Cover	3669	Handle Assembly
2293	Drive Gear Bushing	3654	Counterbalance Cover	3869	Anti-Reverse Lock Out Spring
2857	Trigger Cam	3655	Cover Screw	4051	Bail Spring
3400	Bail Trip Lever	3656	Anti-Reverse Ratchet	4163	Line Roller Bushing
3447	Spool Assembly	3657	Pinion Gear	4185	Body Assembly

(051208)