



TX

2000

'94 TX 2000F

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	3455	Spool Washer	3661	Anti-Reverse Lever Assembly
0041	Drive Gear Washer	3471	Anti-Reverse Cam Spring	3662	Drive Gear
0071	Rotor Nut	3645	Drag Knob	3664	Oscillating Slider
0787	Nut Lock Screw	3646	Main Shaft	3665	Slider Retainer Screw
0792	Bearing Retainer Screw	3648	Quick-Fire II Trigger Assembly	3666	Side Cover Screws
1427	Spool Support	3649	Line Roller	3668	Handle Screw Cap Assembly
1504	Bail Spring Cover Screw	3651	Bail Spring Guide (A)	3670	Rotor
1506	Bail Trip Lever Screw	3652	Bail Spring Guide (B)	3671	Bail Assembly
1890	Bushing Washer	3653	Bail Spring Cover	3672	Counterbalance Cover
2280	Anti-Reverse Lock Out	3655	Cover Screw	3673	Oscillating Gear
2283	Anti-Reverse Pawl Screw	3656	Anti-Reverse Ratchet	3675	Handle Assembly
2293	Drive Gear Bushing	3657	Pinion Gear	3869	Anti-Reverse Lock Out Spring
2857	Trigger Cam	3658	Anti-Reverse Pawl	4051	Bail Spring
3410	Bail Trip Lever	3659	Anti-Reverse Pawl Spring	4163	Line Roller Bushing
3448	Spool Assembly	3660	Anti-Reverse Cam	4186	Body Assembly

(051208)