


## Cruzar™ CRZ 100



Part No.	Description
BNT0042	Line Guide Pawl
BNT0124	Ball Bearing
BNT0133	Worm Shaft Retainer
BNT0191	Multi-Purpose Screw
BNT0194	Ball Bearing
BNT0425	iEi Lock
BNT0664	Spacer (B)
BNT0682	Frame Bar (A) Screw
BNT0686	iEi Lock
BNT0689	Anti-Reverse Pawl Screw
BNT0770	Handle Nut Plate Screw
BNT0797	Handle Nut
BNT0799	Friction Washer
BNT0810	Drag Washer
BNT0816	Shaft Washer
BNT0817	Clutch Cam Retainer Screw
BNT0819	Drive Shaft Bushing
BNT0820	Pinion Gear
BNT0830	Spacer (optional)
BNT1239	Pawl Cap
BNT1245	Clutch Bar Support Spacer
BNT1289	Star Drag Spacer
BNT1419	Yoke Spring
BNT1455	Drag Spring Washer
BNT1456	Drive Gear
BNT1457	Drive Shaft Washer (B)
BNT1458	Anti-Reverse Ratchet
BNT1461	Yoke
BNT1462	Clutch Cam Retainer

Part No.	Description
BNT1465	Clutch Pawl Spring
BNT1472	Anti-Reverse Pawl
BNT1602	Key Washer
BNT1616	Return Pin Guide Screw
BNT1676	Spool Tension Spacer (B)
BNT1677	Spool Tension Spacer (A)
BNT1678	Spool Tension Spring
BNT1692	Handle Nut Plate
BNT1892	Cast Control Cap
BNT1938	Idle Gear (C)
BNT1940	Frame Nut
BNT1941	Stand Screw
BNT1948	Brake Collar
BNT1949	I.D. Plate Screw
BNT2070	Idle Gear (B)
BNT2237	Right Side Plate Screw
BNT2238	Bush Plate Screw
BNT2240	Return Pin Guide
BNT2241	Roller Clutch Assembly
BNT2242	Roller Clutch Inner Tube
BNT2243	A-Side Seal
BNT2244	Drive Shaft
BNT2245	Clutch Cam
BNT2246	Clutch Pawl
BNT2247	Clutch Plate
BNT2248	Set Plate
BNT2249	Bearing Retainer
BNT2250	Line Guide
BNT2251	Worm Bushing (A)

Part No.	Description
BNT2252	Worm Shaft
BNT2253	Drive Shaft Cover Screw
BNT2254	Drive Shaft Cover
BNT2255	A-Side Frame
BNT2256	Level Wind Guard
BNT2257	Stabilizer Bar
BNT2259	Frame Bar (A)
BNT2261	Stand
BNT2262	Clutch Button Guide
BNT2263	Quick-Fire II Clutch Button
BNT2264	Clutch Button Support Bar
BNT2265	B-Side Frame
BNT2266	B-Side Frame Nut
BNT2267	Worm Bushing (B)
BNT2268	Brake Case
BNT2269	B-Side Seal
BNT2271	Left Side Plate Screw
BNT2282	Handle Assembly
BNT2283	Right Side Plate
BNT2284	Thumb Rest
BNT2285	Spool Assembly
BNT2286	Left Side Plate
BNT2287	Left Side I.D. Plate
BNT2292	Star Drag
BNT2293	Right Side Plate Nut
BNT2305	Stand Bolt
BNT2341	Idle Gear (A)