


SUSTAIN® 1000FB 00



Part No.	Description	Part No.	Description	Part No.	Description
RD 0041	Drive Gear Washer	RD 6042	Friction Ring	RD 6301	Bail Arm
RD 0071	Rotor Nut	RD 6043	Anti-Reverse Cam	RD 6302	Line Roller Screw
RD 0806	Bail Hold Support Screw	RD 6044	Anti-Reverse Cam Spring	RD 6303	Protector Screw (A)
RD 0930	Ball Bearing	RD 6047	Idle Gear	RD 6304	Protector Screw (B)
RD 2254	Ball Bearing	RD 6049	Bushing	RD 6305	Rotor Protector
RD 2298	Spacer	RD 6050	Drive Gear	RD 6306	Trip Lever Spacer
RD 2309	Side Cover Screw (short)	RD 6053	Rear Shield	RD 6307	Bail Hold Support Shaft
RD 2401	Ball Bearing	RD 6059	Oscillating Pawl Cover	RD 6308	Bail Hold Support Spacer
RD 2409	Worm Shaft Spacer	RD 6060	Oscillating Slider Bushing	RD 6309	Bail Assembly
RD 2934	Clutch Cover Screw	RD 6061	Oscillating Pawl	RD 6310	Rotor
RD 3455	Spool Washer	RD 6062	Oscillating Slider	RD 6311	Rotor Spacer
RD 3456	Spool Support	RD 6063	Worm Shaft Retainer	RD 6312	Pinion Gear
RD 3571	Anti-Reverse Cam Screw	RD 6064	Worm Shaft Retainer Washer	RD 6313	Worm Bushing
RD 3600	Worm Shaft Retainer Screw	RD 6077	Click Pin	RD 6314	Worm Shaft
RD 4661	Anti-Reverse Cam Ring	RD 6287	Drag Knob	RD 6315	Side Cover
RD 4674	Side Cover Screw	RD 6288	Spool Assembly	RD 6316	Side Cover Flange
RD 4675	Oscillating Pawl Cover Screw	RD 6289	Nut Lock Screw	RD 6317	Rear Protector
RD 4684	iEi Lock	RD 6290	Rotor Nut Lock Plate	RD 6318	Rear Protector Screw
RD 4716	Lever Spring Guide (B)	RD 6291	Main Shaft Spacer	RD 6319	Handle Screw Cap (A)
RD 4717	Lever Spring	RD 6292	Main Shaft	RD 6320	Cap Screw
RD 4718	Lever Spring Guide (A)	RD 6293	Line Roller Bushing	RD 6321	Handle Assembly
RD 4749	Bail Arm Screw	RD 6294	Line Roller Spacer	RD 6322	Oscillating Guide (A)
RD 5261	Slider Retainer Screw	RD 6295	Line Roller Washer	RD 6323	Oscillating Guide (B)
RD 6018	Ball Bearing	RD 6296	Click Spring	RD 6324	Anti-Reverse Lever
RD 6033	Bail Trip Lever	RD 6297	Bail Spring Guide (A)	RD 6325	Body
RD 6035	Line Roller	RD 6298	Bail Spring	RD 6326	Handle Screw Cap (B)
RD 6039	Roller Clutch Screw	RD 6299	Bail Spring Guide (B)		
RD 6040	Roller Clutch Assembly	RD 6300	Bail Spring Cover		