


SUSTAIN® 5000FB₀₀



Part No.	Description
RD 0521	Rotor Nut
RD 0806	Bail Hold Support Screw
RD 1506	Clutch Cover Screw
RD 2254	Ball Bearing
RD 2298	Spacer
RD 3182	Spool Support
RD 3204	Ball Bearing
RD 3306	Ball Bearing
RD 3309	Line Roller Screw
RD 3503	Spool Washer
RD 3561	Worm Shaft Retainer Screw (small)
RD 3600	Worm Shaft Retainer Screw (large)
RD 3936	Anti-Reverse Cam Screw
RD 4656	Trip Lever Spacer
RD 4675	Oscillating Pawl Cover Screw
RD 4716	Lever Spring Guide (B)
RD 4718	Lever Spring Guide (A)
RD 4723	Worm Bushing Rear
RD 5823	Lever Spring Guide (A)
RD 5825	Lever Spring Guide (B)
RD 5880	Nut Lock Screw
RD 5925	Bail Trip Lever Spring
RD 6166	Line Roller
RD 6179	Bearing Washer
RD 6181	Friction Ring
RD 6182	Anti-Reverse Cam
RD 6186	Idle Gear
RD 6188	Worm Shaft Ring
RD 6190	Ball Bearing

Part No.	Description
RD 6191	Drive Gear
RD 6192	Drive Gear Washer
RD 6197	Rear Shield
RD 6202	Side Cover Screw (long)
RD 6203	Side Cover Screw (short)
RD 6204	Oscillating Pawl Cover
RD 6205	Oscillating Slider Bushing
RD 6206	Oscillating Pawl
RD 6207	Oscillating Slider
RD 6208	Set Screw
RD 6209	Slider Retainer Screw
RD 6210	Worm Shaft Retainer Spacer
RD 6211	Worm Shaft Retainer
RD 6212	Worm Shaft Retainer Washer
RD 6213	Oscillating Guide (A)
RD 6214	Oscillating Guide (B)
RD 6216	iO Ring
RD 6307	Bail Hold Support Shaft
RD 6318	Rear Protector Screw (A)
RD 6320	Cap Screw
RD 6329	Bearing Spacer
RD 6330	Line Roller Bushing
RD 6331	Line Roller Spacer
RD 6332	Line Roller Washer
RD 6374	Drag Knob
RD 6375	Spool Assembly
RD 6376	Rotor Nut Lock Plate
RD 6377	Main Shaft Spacer
RD 6378	Main Shaft

Part No.	Description
RD 6379	Bail Arm Screw
RD 6380	Bail Spring Guide (A)
RD 6381	Spring Guide (A) Support
RD 6382	Bail Spring
RD 6383	Bail Spring Guide (B)
RD 6384	Bail Spring Cover
RD 6385	Bail Arm
RD 6386	Protector Screw (A)
RD 6387	Protector Screw (B)
RD 6388	Rotor Protector
RD 6389	Bail Trip Lever
RD 6390	Bail Hold Support Spacer
RD 6391	Bail Assembly
RD 6392	Rotor
RD 6393	Lever Spring
RD 6394	Roller Clutch Screw
RD 6395	Roller Clutch Assembly
RD 6396	Pinion Gear
RD 6397	Worm Bushing (front)
RD 6398	Worm Shaft
RD 6399	Side Cover
RD 6400	Side Cover Flange
RD 6401	Rear Protector
RD 6402	Rear Protector Screw (B)
RD 6403	Handle Screw Cap (A)
RD 6404	Handle Assembly
RD 6405	Anti-Reverse Lever
RD 6406	Body
RD 6407	Handle Screw Cap (B)