


SYNCOPATE® 1000FA 00



Part No.	Description
RD 0026	Ball Bearing
RD 0041	Drive Gear Washer
RD 0050	Anti-Reverse Lever Screw
RD 0071	Rotor Nut
RD 0540	Multi-Purpose Screw
RD 0642	Side Cover Screw
RD 0779	Bail Hold Support Screw
RD 0786	Trigger Screw
RD 0787	Nut Lock Screw
RD 0792	Bearing Retainer Screw
RD 0930	Ball Bearing
RD 1008	Handle Lock Washer
RD 1427	Spool Support
RD 1890	Bushing Washer
RD 1891	Bail Spring Cover Screw
RD 2280	Anti-Reverse Lock Out
RD 2283	Anti-Reverse Pawl Screw
RD 2293	Drive Gear Bushing
RD 2852	Handle Screw Lock
RD 3359	Line Roller Washer

Part No.	Description
RD 3400	Bail Trip Lever
RD 3402	Cover Screw
RD 3450	Spool Assembly (graphite)
RD 3455	Spool Washer
RD 3471	Anti-Reverse Cam Spring
RD 3646	Main Shaft
RD 3651	Bail Spring Guide (A)
RD 3652	Bail Spring Guide (B)
RD 3656	Anti-Reverse Ratchet
RD 3657	Pinion Gear
RD 3658	Anti-Reverse Pawl
RD 3659	Anti-Reverse Pawl Spring
RD 3660	Anti-Reverse Cam
RD 3662	Drive Gear
RD 3663	Oscillating Gear
RD 3664	Oscillating Slider
RD 3665	Slider Retainer Screw
RD 3700	Rotor
RD 3702	Bail Spring Cover
RD 3703	Counterbalance Cover

Part No.	Description
RD 3869	Anti-Reverse Lock Out Spring
RD 4051	Bail Spring
RD 4160	Trigger Cam
RD 4364	Quick-Fire II Trigger
RD 4366	Bail Arm
RD 4367	Line Roller Screw
RD 4421	Handle Screw Cap
RD 4885	Drag Knob
RD 4886	Spool Assembly (aluminum)
RD 4890	Anti-Reverse Lever
RD 4927	Side Cover
RD 4928	Body
RD 5546	Handle Assembly
RD 5625	Line Roller Spacer
RD 5628	Line Roller Collar
RD 5629	Line Roller Bushing
RD 5630	Line Roller
RD 6733	Bail Assembly