


SYNCOPE® 4000FA 00



Part No.	Description
RD 0026	Ball Bearing
RD 0041	Drive Gear Washer
RD 0050	Anti-Reverse Lever Screw
RD 0071	Rotor Nut
RD 0540	Multi-Purpose Screw
RD 0642	Side Cover Screw (small)
RD 0779	Bail Hold Support Screw
RD 0786	Trigger Screw
RD 0787	Nut Lock Screw
RD 0792	Bearing Retainer Screw
RD 0930	Ball Bearing
RD 1008	Handle Lock Washer
RD 1511	Lever Spring
RD 1520	Anti-Reverse Cam Spring
RD 2293	Drive Gear Bushing
RD 2516	Spool Support
RD 2541	Anti-Reverse Pawl Screw
RD 2852	Handle Screw Lock
RD 2934	Flange Screw
RD 3359	Line Roller Washer
RD 3402	Cover Screw

Part No.	Description
RD 3452	Spool Assembly (graphite)
RD 3503	Spool Washer
RD 3665	Slider Retainer Screw
RD 3677	Main Shaft
RD 3681	Bail Spring Guide (A)
RD 3682	Bail Spring
RD 3683	Bail Spring Guide (B)
RD 3685	Bail Trip Lever
RD 3687	Anti-Reverse Ratchet
RD 3688	Anti-Reverse Lock Out
RD 3689	Bushing Washer
RD 3690	Pinion Gear
RD 3691	Anti-Reverse Pawl
RD 3692	Anti-Reverse Pawl Spring
RD 3693	Anti-Reverse Cam
RD 3694	Drive Gear
RD 3695	Oscillating Gear
RD 3696	Oscillating Slider
RD 3710	Rotor
RD 3712	Bail Spring Cover
RD 3713	Counterbalance Cover

Part No.	Description
RD 3869	Anti-Reverse Lock Out Spring
RD 4161	Trigger Cam
RD 4362	Side Cover Screw (large)
RD 4367	Line Roller Screw
RD 4373	Quick-Fire II Trigger
RD 4375	Bail Arm
RD 4421	Handle Screw Cap
RD 4890	Anti-Reverse Lever
RD 4897	Drag Knob
RD 4898	Spool Assembly (aluminum)
RD 4930	Side Cover Flange
RD 4931	Side Cover
RD 4932	Body
RD 5548	Handle Assembly
RD 5625	Line Roller Spacer
RD 5628	Line Roller Collar
RD 5629	Line Roller Bushing
RD 5630	Line Roller
RD 6735	Bail Assembly