


SAHARA™ 6000FA 00



Part No.	Description
RD 0050	Anti-Reverse Lever Screw
RD 0521	Rotor Nut
RD 0690	Drive Gear Washer
RD 0959	Bail Hold Support Screw
RD 0998	Rotor Protector Screw (large)
RD 1008	Handle Lock Washer
RD 1109	Slider Retainer Screw
RD 1506	Clutch Cover Screw
RD 3182	Spool Support
RD 3204	Ball Bearing
RD 3309	Line Roller Screw
RD 3387	Handle Screw Lock
RD 3503	Spool Washer
RD 4362	Side Cover Screw (long)
RD 4416	Rotor Protector Screw (small)
RD 4649	Spacer
RD 4656	Trip Lever Spacer
RD 5040	Roller Clutch Screw
RD 5042	Anti-Reverse Cam Ring
RD 5208	Anti-Reverse Lever
RD 5440	Drag Knob
RD 5447	Roller Clutch Assembly

Part No.	Description
RD 5449	Anti-Reverse Cam
RD 5455	Anti-Reverse Cam Spring
RD 5625	Line Roller Spacer
RD 5628	Line Roller Collar
RD 5629	Line Roller Bushing
RD 5642	Line Roller
RD 5823	Lever Spring Guide (A)
RD 5825	Lever Spring Guide (B)
RD 5880	Nut Retainer Screw
RD 6377	Main Shaft Spacer
RD 6379	Bail Arm Screw
RD 6380	Bail Spring Guide (A)
RD 6383	Bail Spring Guide (B)
RD 6539	Bail Trip Lever
RD 6540	Bail Hold Support Spacer
RD 6544	Friction Ring
RD 6639	Side Cover Screw (short)
RD 6676	Bail Arm
RD 6686	Click Spring
RD 6687	Bail Arm Click
RD 6692	Bail Hold Support Shaft
RD 6703	Line Roller Washer

Part No.	Description
RD 6756	Spool Assembly
RD 6757	Nut Retainer
RD 6758	Main Shaft
RD 6760	Bail Spring Guide (A) Collar
RD 6761	Bail Spring
RD 6764	Spacer
RD 6767	Bail Trip Lever Spring
RD 6768	Roller Clutch Screw Washer
RD 6769	Pinion Gear
RD 6770	Bushing
RD 6771	Drive Gear
RD 6772	Drive Gear Spacer
RD 6774	Oscillating Slider
RD 6775	Oscillating Gear
RD 6776	Oscillating Gear Bushing
RD 6782	Bail Assembly
RD 6783	Handle Screw Cap
RD 6784	Handle Assembly
RD 6785	Body Assembly
RD 6786	Rotor Assembly