


## THUNNUS™ 16000F



Part No.	Description
RD 0088	Line Roller Screw
RD 0113	Tension Spring Washer (B)
RD 0244	Ball Bearing
RD 0266	IC Lock
RD 0540	Multi-Purpose Screw (A)
RD 0543	Rear Protector Screw (long)
RD 0693	Free Spool Tension Washer (cloth)
RD 0714	Rotor Nut
RD 0743	Drive Gear Washer
RD 1506	Roller Clutch Cover Screw
RD 1676	Side Cover Screw
RD 1891	Multi-Purpose Screw (B)
RD 2298	Spacer
RD 2409	Worm Shaft Spacer
RD 2613	Lock Washer
RD 2614	Clutch Arm Screw
RD 2615	BaitRunner Lever Screw
RD 3016	Click Gear
RD 3017	Free Spool Tension Washer (B)
RD 3033	BaitRunner Ratchet
RD 3034	Ratchet Spacer
RD 3204	Ball Bearing
RD 3306	Line Roller Bearing
RD 3600	Nut Lock Screw
RD 4743	Line Roller Bushing
RD 4744	Roller Bearing Seal
RD 4763	Roller Clutch Assembly
RD 5040	Roller Clutch Screw
RD 5042	Anti-Reverse Cam Ring
RD 5705	Roller Clutch Ring
RD 5717	Ball Bearing
RD 5795	Drag Knob
RD 5796	Spool Assembly
RD 5797	Spool Washer
RD 5798	Spool Support
RD 5799	Rotor Nut Retainer
RD 5800	Main Shaft
RD 5801	Line Roller Washer

Part No.	Description
RD 5802	Line Roller Screw Cap
RD 5803	Bail Spring Guide (A)
RD 5804	Spring Guide (A) Support
RD 5805	Bail Spring
RD 5806	Bail Spring Guide (B)
RD 5807	Bail Spring Cover
RD 5808	Bail Arm Washer
RD 5809	Line Roller Support Collar
RD 5810	Bail Arm
RD 5811	Bail Arm Screw
RD 5812	Bail Arm Screw Collar
RD 5813	Guard Screw (A)
RD 5814	Guard Screw (B)
RD 5815	Bail Spring Cover Guard
RD 5816	Bail Trip Lever
RD 5817	Bail Hold Support Shaft
RD 5818	Bail Assembly
RD 5819	Bail Hold Support Screw
RD 5820	Spacer
RD 5821	Bail Hold Support Spacer
RD 5822	Rotor
RD 5823	Lever Spring Guide (A)
RD 5825	Lever Spring Guide (B)
RD 5826	Pinion Gear
RD 5827	Body
RD 5828	Worm Bushing (front)
RD 5832	Worm Bushing (rear)
RD 5833	Anti-Reverse Cam
RD 5834	Anti-Reverse Cam Spring
RD 5835	Anti-Reverse Lever
RD 5836	Anti-Reverse Lever Screw
RD 5837	Oscillating Slider
RD 5838	Oscillating Pawl
RD 5839	Oscillating Pawl Bushing
RD 5840	Oscillating Slider Retainer
RD 5841	Slider Retainer Screw
RD 5842	Drive Gear Ratchet Spacer
RD 5843	Drive Gear Ratchet

Part No.	Description
RD 5844	Drive Gear
RD 5845	Side Cover Flange
RD 5846	Handle Screw Cap
RD 5847	Side Cover
RD 5848	BaitRunner Pawl
RD 5849	Spring Retainer
RD 5850	BaitRunner Pawl Spring
RD 5851	Worm Shaft Retainer
RD 5852	Dial Click
RD 5853	BaitRunner Pawl Guide
RD 5854	Oscillating Guide
RD 5855	Oscillating Guide Holder
RD 5856	BaitRunner Lever Bridge
RD 5857	BaitRunner Lever Arm (L)
RD 5858	BaitRunner Lever Arm (R)
RD 5859	BaitRunner Lever Spacer
RD 5860	Clutch Pawl Guard
RD 5861	Clutch Lever
RD 5862	Clutch Pawl
RD 5863	Clutch Arm Cover
RD 5864	Clutch Arm
RD 5865	Clutch Pawl Spring
RD 5866	Push Nut (SPN-2)
RD 5867	Clutch Spring
RD 5868	Free Spool Tension Shaft
RD 5869	Eared Washer
RD 5870	Free Spool Tension Spring
RD 5872	Free Spool Tension Screw
RD 5873	Dial Retainer
RD 5874	Rear Protector
RD 5875	Rear Protector Screw (short)
RD 5876	BaitRunner Tension Dial
RD 5877	Handle Assembly
RD 5878	Spacer
RD 5997	Line Roller
RD 6286	Bail Trip Lever Spring
RD 6724	Idle Gear (B)
RD 6725	Worm Shaft (B)