


## THUNNUS™ 6000F 99



Part No.	Description
RD 0113	Tension Spring Washer
RD 0266	ICF Lock
RD 0543	Side Cover Screw (B)
RD 0693	Free Spool Tension Washer (cloth)
RD 0743	Drive Gear Washer
RD 1506	Roller Clutch Cover Screw
RD 1637	Slider Retainer Screw
RD 1676	Side Cover Screw (A)
RD 1707	Bushing Washer
RD 2254	Ball Bearing
RD 2409	Spacer
RD 2613	Lock Washer
RD 2614	Clutch Arm Screw
RD 2981	Free Spool Tension Spring
RD 3016	Click Gear
RD 3017	Free Spool Tension Washer (B)
RD 3019	Free Spool Tension Screw
RD 3033	BaitRunner Ratchet
RD 3034	Ratchet Spacer
RD 3041	BaitRunner Pawl
RD 3182	Spool Support
RD 3204	Ball Bearing
RD 3306	Line Roller Bearing
RD 3503	Spool Washer
RD 3962	Spacer
RD 4718	Lever Spring Guide (A)
RD 5042	Anti-Reverse Cam Ring
RD 5261	Nut Lock Screw
RD 5447	Roller Clutch Assembly
RD 5625	Line Roller Spacer
RD 5696	Clutch Pawl Guard Screw
RD 5701	Lever Spring Guide (B)
RD 5705	Roller Clutch Ring
RD 5813	Guard Screw (A)
RD 5817	Bail Hold Support Shaft
RD 5819	Bail Hold Support Screw
RD 5836	Anti-Reverse Lever Screw
RD 5842	Drive Gear Ratchet Spacer

Part No.	Description
RD 5843	Drive Gear Ratchet
RD 5846	Handle Screw Cap
RD 5850	BaitRunner Pawl Spring
RD 5859	BaitRunner Lever Spacer
RD 5875	Rear Protector Screw (A)
RD 5905	Drag Knob
RD 5906	Spool Assembly
RD 5907	Main Shaft
RD 5908	Rotor Nut
RD 5909	Line Roller Bushing
RD 5910	Line Roller
RD 5911	Line Roller Washer
RD 5912	Bail Spring Guide (A)
RD 5915	Bail Spring Guide (B)
RD 5916	Bail Spring Cover
RD 5917	Bail Arm Washer
RD 5918	Bail Arm
RD 5919	Line Roller Screw
RD 5920	Bail Arm Screw
RD 5921	Bail Arm Screw Collar
RD 5922	Guard Screw (B)
RD 5923	Bail Spring Cover Guard
RD 5924	Bail Trip Lever
RD 5926	Bail Assembly
RD 5927	Bail Hold Support Spacer
RD 5928	Rotor
RD 5929	Pinion Gear
RD 5930	Body
RD 5931	Worm Bushing (front)
RD 5932	Idle Gear
RD 5933	Worm Shaft
RD 5934	Worm Bushing (rear)
RD 5935	Anti-Reverse Cam
RD 5936	Anti-Reverse Lever
RD 5937	Oscillating Slider
RD 5938	Oscillating Slider Retainer
RD 5939	Drive Gear
RD 5940	Side Cover Flange

Part No.	Description
RD 5941	Side Cover Screw (C)
RD 5942	Side Cover
RD 5943	BaitRunner Pawl Guide
RD 5944	BaitRunner Pawl Guide Screw
RD 5945	Worm Shaft Retainer
RD 5946	Dial Retainer
RD 5947	Dial Click Screw
RD 5948	Dial Click
RD 5949	Spring Retainer
RD 5950	Oscillating Guide
RD 5951	Oscillating Guide Holder
RD 5952	BaitRunner Lever Bridge
RD 5953	BaitRunner Lever Arm (L)
RD 5954	BaitRunner Lever Screw
RD 5955	Anti-Reverse Cam Spring
RD 5956	BaitRunner Lever Arm (R)
RD 5957	Clutch Pawl Guard
RD 5958	Clutch Lever
RD 5959	Clutch Pawl
RD 5960	Clutch Arm Cover
RD 5961	Clutch Arm
RD 5962	Clutch Spring
RD 5963	Clutch Pawl Spring
RD 5964	Free Spool Tension Shaft
RD 5965	Eared Washer
RD 5966	Rear Protector
RD 5967	Rear Protector Screw (B)
RD 5968	BaitRunner Tension Dial
RD 5969	Handle Assembly
RD 5998	Rotor Nut Retainer
RD 6283	Roller Clutch Screw
RD 6284	Oscillating Pawl
RD 6285	Oscillating Slider Bushing
RD 6289	Spring Retainer Screw
RD 6475	Spring Guide (A) Support
RD 6476	Bail Spring
RD 6477	Bail Trip Lever Spring