


Assembly : **IR410CX**

Schematic View



Assembly : **IR410CX**

Part List

KEY No.	PART No.	PRICE	DESCRIPTION	COMMENTS	KEY No.	PART No.	PRICE	DESCRIPTION	COMMENTS
1	FV323-02	17.26	Left Side Cover Assy	-	46	JX066-02	4.08	Crank Shaft Guide	-
2	XX038-02	0.32	Spool Shaft Washer	-	47	JX073-01	0.38	O-Ring - Thumb Screw	-
3	JX106-01	7.73	Bearing - Spool Shaft	-	48	XX374-03	1.53	Thumb Screw Assy	-
4	JX080-01	0.32	Clip Ring	-	49	XX024-07	11.89	Right Side Cover	-
5	FV321-01	17.16	Spool Assy	-	50	QW123-01	0.17	Right Side Cover Screw	-
6	XX044-01	0.32	Brake Shoe B	-	51	JX105-01	0.38	Spring - Tension Knob	-
7	JX106-01	7.73	Bearing - Spool Shaft	-	52	QW032-02	0.32	Washer - Spool Tension	-
8	FV301-02	30.75	Frame Assy	-	53	JX082-01	0.26	Washer - Cushion	-
9	QW120-01	0.32	E-Clip - Worm Shaft	-	54	XX033-01	3.44	Spool Tension Knob	-
10	JX067-01	0.38	Bushing - Worm Shaft	-	55	JX046-01	0.82	Spring "D" Washer	-
11	JX347-02	2.83	Line Guide Carrier Assy	-	56	XX355-02	4.21	Star Drag Assy	-
12	JX006-02	2.2	Line Guide Pawl	-	57	NX054-01	0.32	Handle Washer	-
13	JX035-01	0.32	Washer - Line Guide Pawl	-	58	JV318-01	8.54	Handle Assy	-
14	JX007-02	0.64	Screw - Line Guide Carrier	-	59	QW003-01	0.44	Handle Nut	-
15	NX092-01	0.37	E-Clip - Kick Lever Guide Post	-	60	JX034-02	0.44	Handle Nut Cap	-
16	XX035-01	0.32	Washer - Kick Lever Guide	-	61	QW123-01	0.17	Handle Nut Cap Screw	-
17	JX050-01	0.38	Screw - Thumb Rest	-	62	UQ063-02	11.32	One Way Bearing	-
18	FV009-01	0.79	Thumb Rest	-	64	XX125-01	1.2	Screw - Clicker Pawl	-
19	FV061-01	1.22	Line Guide Carrier Guide	-	65	JX110-01	0.26	Clicker Spring	-
20	FV016-01	0.91	Worm Shaft Guide	-	66	JX114-01	0.85	Clicker Pawl	-
21	FV372-01	9.09	Worm Shaft Assy	-	67	JX084-01	3.52	Clicker Cam	-
22	JX025-01	0.64	Pinion Yoke	-	68	JX125-01	0.26	Screw - Clicker Spring Holder	-
23	JX040-01	0.26	Yoke Spring	-	69	JX103-01	1.47	Clicker Spring Holder	-
24	XX011-01	6.54	Bushing Gear	-	70	JX022-01	0.32	Spring - Clicker Cam	-
25	JX017-01	0.93	Bushing - Crank Shaft (L)	-	71	JX041-01	0.44	Click Cam Actuator	-
26	QW120-01	0.32	E-Clip - Crank Shaft	-	72	JX075-01	0.26	C-Clip	-
27	JX002-01	0.7	Retainer - Crank Shaft	-	73	JX109-02	0.64	Click Lever	-
28	JX107-01	0.17	Screw - Crank Shaft Retainer	-	74	QW053-05	0.32	Screw - Click Lever	-
29	JX077-01	0.7	Kick Lever	-	76	JX121-01	0.26	Washer - Thumb Screw	-
30	JX097-01	0.17	Spring - Kick Lever	-	77	FV098-01	0.62	Idel Gear Post	-
31	JX068-01	1.31	Bushing Release Slider Guide	-	78	FV127-01	1.22	O/S Idel Gear	-
32	JX104-01	0.83	Spring Release Slider	-	79	FV351-01	8.12	Spool Assy	-
33	XX050-01	0.17	Screw - Release Slider	-	80	AV125-01	0.85	Spool Cover Screw	-
34	JX339-02	2.2	Release Slider Assy	-					
35	JX102-01	1.08	Post - Kick Lever Guide	-					
36	JX008-01	3.52	Crank Shatt	-					
37	FV112-01	0.62	O/S Drive Gear	-					
38	JX083-01	1.14	Trip Ratchet	-					
39	JX111-01	0.55	Washer- Ratchet	-					
40	XX012-01	9.36	Drive Gear	-					
41	JX059-01	1.44	Drag Disc	-					
42	JX045-01	1.08	Drag "D" Washer	-					
43	CW052-01	3.52	Sleeve - One Way Bearing	-					
44	TW058-01	8.8	Bearing - Crank Shaft (U)	-					
45	JX038-01	0.38	Crank Shaft Washer	-					